

OUTDOOR UNIT

SERVICE MANUAL




**No. OBH946
REVISED EDITION-B**

Models

MUZ-FX06NLHZ	- U1
MUZ-FX09NLHZ	- U1
MUZ-FX12NLHZ	- U1
MUZ-FX15NLHZ	- U1
MUZ-FX18NLHZ	- U1
MUZ-FX24NLHZ	- U1

Indoor unit service manual
MSZ-FX•NL Series (OBH945)



**MUZ-FX06NLHZ
MUZ-FX09NLHZ
MUZ-FX12NLHZ**

CONTENTS

• SERVICING PRECAUTIONS FOR UNITS USING REFRIGERANT R454B	3
1. TECHNICAL CHANGES	8
2. PART NAMES AND FUNCTIONS	9
3. SPECIFICATION	10
4. OUTLINES AND DIMENSIONS	13
5. WIRING DIAGRAM	15
6. REFRIGERANT SYSTEM DIAGRAM	16
7. DATA.....	18
8. ACTUATOR CONTROL	35
9. SERVICE FUNCTIONS	36
10. TROUBLESHOOTING	37
11. DISASSEMBLY INSTRUCTIONS	62

PARTS CATALOG (OBB946)

Use the specified refrigerant only

Never use any refrigerant other than that specified.

Doing so may cause a burst, an explosion, or fire when the unit is being used, serviced, or disposed of.

Correct refrigerant is specified in the manuals and on the spec labels provided with our products.

We will not be held responsible for mechanical failure, system malfunction, unit breakdown or accidents caused by failure to follow the instructions.

<Preparation before the repair service>

- Prepare the proper tools.
- Prepare the proper protectors.
- Provide adequate ventilation.
- After stopping the operation of the air conditioner, turn off the power-supply breaker and pull the power plug.
- Discharge the capacitor before the work involving the electric parts.

<Precautions during the repair service>

- Do not perform the work involving the electric parts with wet hands.
- Do not pour water into the electric parts.
- Do not touch the refrigerant.
- Do not touch the hot or cold areas in the refrigeration cycle.
- When the repair or the inspection of the circuit needs to be done without turning off the power, exercise great caution not to touch the live parts.

WARNING

- When the refrigerant circuit has a leak, do not execute pump down with the compressor.
- When pumping down the refrigerant, stop the compressor before disconnecting the refrigerant pipes.
The compressor may burst if air etc. get into it.
- When opening or closing the valve below freezing temperatures, refrigerant may spurt out from the gap between the valve stem and the valve body, resulting in injuries.

Revision A:

- 3. SPECIFICATION has been corrected.

Revision B:

- 3. SPECIFICATION has been corrected.

SERVICING PRECAUTIONS FOR UNITS USING REFRIGERANT R454B

Servicing precautions for units using refrigerant R454B



Refrigerant
Safety Group
A2L

WARNING

This unit uses a flammable refrigerant.

If refrigerant leaks and comes in contact with fire or heating part, it will create harmful gas and there is risk of fire.

Do not use means to accelerate the defrosting process or to clean, other than those recommended by the manufacturer. The appliance should not be stored in a room with continuously operating ignition sources (for example: open flames, an operating gas appliance, or an operating electric heater).

Do not pierce or burn.

Be aware that refrigerants may not contain an odor.

- Maintenance, service and repair operations shall be performed by authorized technician with required qualification.
- Servicing shall be performed only by methods recommended by the manufacturer.
- Refrigerant piping shall be protected from physical damage.
- Field installed piping should be kept to a minimum.
- Compliance with national gas regulations shall be observed.
- All field joints shall be accessible for inspection prior to being covered or enclosed.

⚠️ WARNING

- The mounting height of indoor unit shall be 5.9 ft (1.8 m) or more from the floor. Up to 7.5 ft (2.3 m) is recommended.
- The unit shall be installed in rooms exceed the minimum room area (A_{min}) determined by total refrigerant amount (M).

NOTE: For the corresponding table of the branch box system, refer to the multi-unit installation manual.

SYSTEM WITHOUT BRANCH BOX

M		A_{min}	
[kg]	[lbs, oz]	[m ²]	[ft ²]
0.5	1 1	1.9	21
0.6	1 5	2.3	25
0.7	1 8	2.6	28
0.8	1 12	3.0	33
0.9	1 15	3.4	37
1.0	2 3	3.8	41
1.1	2 6	4.1	45
1.2	2 10	4.5	49
1.3	2 13	4.9	53
1.4	3 1	5.2	56
1.5	3 4	5.6	61
1.6	3 8	6.0	65

M		A_{min}	
[kg]	[lbs, oz]	[m ²]	[ft ²]
1.7	3 11	6.3	68
1.8	3 15	6.8	74
1.9	4 3	7.2	78
2.0	4 6	7.6	82
2.1	4 10	7.9	86
2.2	4 13	8.3	90
2.3	5 1	8.7	94
2.4	5 4	9.1	98
2.5	5 8	9.4	102
2.6	5 11	9.8	106
2.7	5 15	10.2	110
2.8	6 2	10.6	115

1. REFRIGERANT PIPE NITROGEN PRESSURE TEST METHOD

- (1) Connect the testing tools.
 - Make sure the stop valves are closed and do not open them.
 - Add pressure to the refrigerant lines through the service port of the stop valve for GAS.
- (2) Do not add pressure to the specified pressure all at once; add pressure little by little.
 1. Pressurize to 0.5 MPa (73 psig, 5 kgf/cm²G), wait 5 minutes, and make sure the pressure does not decrease.
 2. Pressurize to 1.5 MPa (218 psig, 15 kgf/cm²G), wait 5 minutes, and make sure the pressure does not decrease.
 3. Pressurize to 4.15 MPa (601 psig, 41.5 kgf/cm²G) and measure the surrounding temperature and refrigerant pressure.
- (3) If the specified pressure holds for 24 Hours and does not decrease, the pipes have passed the test and there are no leaks.
 - If the surrounding temperature changes by 1°F (0.5°C), the pressure will change by about 1 psig (0.007 MPa). Make the necessary corrections.
- (4) If the pressure decreases in steps (2) or (3), there is a gas leak. Look for the source of the gas leak.

2. Additional refrigerant charge

Additional refrigerant charge

Refrigerant for the indoor units and the extended piping is not included in the outdoor unit when the unit is shipped from the factory. Therefore, charge each refrigerant piping system with additional refrigerant at the installation site. In addition, in order to carry out service, enter the size and length of each liquid pipe and additional refrigerant charge amounts in the spaces provided on the "Refrigerant amount" plate on the outdoor unit.

NOTE:

- When the unit is stopped, charge the unit with the additional refrigerant through the liquid stop valve after the pipe extensions and indoor units have been vacuumized.
- When the unit is operating, add refrigerant to the gas check valve using a safety charger. Do not add liquid refrigerant directly to the check valve.

Refrigerant adjustment *1

Model	MSZ-FX06/09/12NL	MSZ-FX15/18/24NL
Chargeless pipe length A	25 ft (7.5 m)	50 ft (15 m)
Refrigerant adjustment B	0.22 oz/ft (20 g/m)	
Additional refrigerant	Pipe length up to A : No need Pipe length exceeds A : B×(pipe length - A)	

*1 When installing multi units, refer to the installation manual of the multi outdoor unit for unit installation.

3. REFRIGERANT SENSOR INSTALLATION AND REPLACEMENT

- For system with branch box, the refrigerant sensor shall be installed to the indoor unit before turning on the breaker.
The refrigerant sensor is located inside the branch box package or can be ordered separately Parts Number **MAC-100RS-E**.
- When the refrigerant sensor is installed in the indoor unit, the system may stop operation if refrigerant leaks are detected.
- If the refrigerant sensor fails, replace the refrigerant sensor.
- The refrigerant sensor shall only be replaced with manufacturer approved sensor.
- If the refrigerant sensor error occurs even if the sensor is installed, check the cable connection for the sensor side and the main board side.




Fig. 1




Fig. 2

- (1) Remove the panel right assembly.
- (2) Take out the lead wire. (Fig. 1)
- (3) Connect the lead wire to the refrigerant sensor. (Fig. 1)
- (4) Push the lead wire into the slit so that the refrigerant sensor does not press it.
- (5) Install the refrigerant sensor as shown in the figure. (Fig. 2)

4. Cautions for the unit using R454B refrigerant

Basic work procedures are the same as those for conventional units using refrigerant R410A. However, pay careful attention to the following points.

■ Information on servicing

1. Checks to the area

Prior to beginning work on systems containing FLAMMABLE REFRIGERANTS, safety checks are necessary to ensure that the risk of ignition is minimized. For repair to the REFRIGERATING SYSTEM, 2 to 6 below shall be completed prior to conducting work on the system.

2. Work procedure

Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapour being present while the work is being performed.

3. General work area

All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out. Work in confined spaces shall be avoided.

4. Checking for presence of refrigerant

The area shall be checked with an appropriate refrigerant detector prior to and during work, to ensure the technician is aware of potentially toxic or flammable atmospheres. Ensure that the leak detection equipment being used is suitable for use with all applicable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.

5. Presence of fire extinguisher

If any hot work is to be conducted on the refrigerating equipment or any associated parts, appropriate fire extinguishing equipment shall be available to hand. Have a dry powder or CO₂ fire extinguisher adjacent to the charging area.

6. No ignition sources

No person carrying out work in relation to a REFRIGERATING SYSTEM which involves exposing any pipe work shall use any sources of ignition in such a manner that it may lead to the risk of fire or explosion. All possible ignition sources, including cigarette smoking, should be kept sufficiently far away from the site of installation, repairing, removing and disposal, during which refrigerant can possibly be released to the surrounding space. Prior to work taking place, the area around the equipment is to be surveyed to make sure that there are no flammable hazards or ignition risks. "No Smoking" signs shall be displayed.

7. Ventilated area

Ensure that the area is in the open or that it is adequately ventilated before breaking into the system or conducting any hot work. A degree of ventilation shall continue during the period that the work is carried out. The ventilation should safely disperse any released refrigerant and preferably expel it externally into the atmosphere.

8. Checks to the refrigerating equipment

Where electrical components are being changed, they shall be fit for the purpose and to the correct specification. At all times the manufacturer's maintenance and service guidelines shall be followed. If in doubt, consult the manufacturer's technical department for assistance. The following checks shall be applied to installations using FLAMMABLE REFRIGERANTS:

- the actual REFRIGERANT CHARGE is in accordance with the room size within which the refrigerant containing parts are installed;
- the ventilation machinery and outlets are operating adequately and are not obstructed;
- marking to the equipment continues to be visible and legible. Markings and signs that are illegible shall be corrected;
- refrigerating pipe or components are installed in a position where they are unlikely to be exposed to any substance which may corrode refrigerant containing components, unless the components are constructed of materials which are inherently resistant to being corroded or are suitably protected against being so corroded.

9. Checks to electrical devices

Repair and maintenance to electrical components shall include initial safety checks and component inspection procedures. If a fault exists that could compromise safety, then no electrical supply shall be connected to the circuit until it is satisfactorily dealt with. If the fault cannot be corrected immediately but it is necessary to continue operation, an adequate temporary solution shall be used. This shall be reported to the owner of the equipment so all parties are advised.

Initial safety checks shall include:

- that capacitors are discharged: this shall be done in a safe manner to avoid possibility of sparking;
- that no live electrical components and wiring are exposed while charging, recovering or purging the system;
- that there is continuity of earth bonding.

■ Repairs to sealed components

Sealed electrical components shall be replaced.

■ Repair to intrinsically safe components

Intrinsically safe components must be replaced.

■ Cabling

Check that cabling will not be subject to wear, corrosion, excessive pressure, vibration, sharp edges or any other adverse environmental effects. The check shall also take into account the effects of aging or continual vibration from sources such as compressors or fans.

■ Detection of flammable refrigerants

Under no circumstances shall potential sources of ignition be used in the searching for or detection of refrigerant leaks. A halide torch (or any other detector using a naked flame) shall not be used.

The following leak detection methods are deemed acceptable for all refrigerant systems.

Electronic leak detectors may be used to detect refrigerant leaks but, in the case of FLAMMABLE REFRIGERANTS, the sensitivity may not be adequate, or may need re-calibration. (Detection equipment shall be calibrated in a refrigerant-free area.) Ensure that the detector is not a potential source of ignition and is suitable for the refrigerant used.

Leak detection equipment shall be set at a percentage of the LFL of the refrigerant and shall be calibrated to the refrigerant employed, and the appropriate percentage of gas (25 % maximum) is confirmed.

Leak detection fluids are also suitable for use with most refrigerants but the use of detergents containing chlorine shall be avoided as the chlorine may react with the refrigerant and corrode the copper pipe-work.

If a leak is suspected, all naked flames shall be removed/extinguished.

If a leakage of refrigerant is found which requires brazing, all of the refrigerant shall be recovered from the system, or isolated (by means of shut off valves) in a part of the system remote from the leak.

■ Removal and evacuation

When breaking into the refrigerant circuit to make repairs - or for any other purpose -conventional procedures shall be used. However, for flammable refrigerants it is important that best practice be followed, since flammability is a consideration.

The following procedure shall be adhered to:

- safely remove refrigerant following local and national regulations;
- evacuate;
- purge the circuit with inert gas;
- evacuate;
- continuously flush or purge with inert gas when using flame to open circuit; and
- open the circuit.

The refrigerant charge shall be recovered into the correct recovery cylinders if venting is not allowed by local and national codes.

For appliances containing flammable refrigerants, the system shall be purged with oxygen-free nitrogen to render the appliance safe for flammable refrigerants. This process might need to be repeated several times.

Compressed air or oxygen shall not be used for purging refrigerant systems.

For appliances containing flammable refrigerants, refrigerants purging shall be achieved by breaking the vacuum in the system with oxygen-free nitrogen and continuing to fill until the working pressure is achieved, then venting to atmosphere, and finally pulling down to a vacuum.

This process shall be repeated until no refrigerant is within the system. When the final oxygen-free nitrogen charge is used, the system shall be vented down to atmospheric pressure to enable work to take place.

The outlet for the vacuum pump shall not be close to any potential ignition sources, and ventilation shall be available.

■ Charging procedures

In addition to conventional charging procedures, the following requirements shall be followed.

- Ensure that contamination of different refrigerants does not occur when using charging equipment. Hoses or lines shall be as short as possible to minimize the amount of refrigerant contained in them.
- Cylinders shall be kept in an appropriate position according to the instructions.
- Ensure that the REFRIGERATING SYSTEM is earthed prior to charging the system with refrigerant.
- Label the system when charging is complete (if not already).
- Extreme care shall be taken not to overfill the REFRIGERATING SYSTEM.

Prior to recharging the system, it shall be pressure-tested with the appropriate purging gas. The system shall be leak-tested on completion of charging but prior to commissioning. A follow up leak test shall be carried out prior to leaving the site.

■ Decommissioning

Before carrying out this procedure, it is essential that the technician is completely familiar with the equipment and all its detail. It is recommended good practice that all refrigerants are recovered safely. Prior to the task being carried out, an oil and refrigerant sample shall be taken in case analysis is required prior to re-use of recovered refrigerant. It is essential that electrical power is available before the task is commenced.

- Become familiar with the equipment and its operation.
- Isolate system electrically.
- Before attempting the procedure, ensure that:
 - mechanical handling equipment is available, if required, for handling refrigerant cylinders;
 - all personal protective equipment is available and being used correctly;
 - the recovery process is supervised at all times by a competent person;
 - recovery equipment and cylinders conform to the appropriate standards.
- Pump down refrigerant system, if possible.
- If a vacuum is not possible, make a manifold so that refrigerant can be removed from various parts of the system.
- Make sure that cylinder is situated on the scales before recovery takes place.
- Start the recovery machine and operate in accordance with instructions.
- Do not overfill cylinders (no more than 80 % volume liquid charge).
- Do not exceed the maximum working pressure of the cylinder, even temporarily.
- When the cylinders have been filled correctly and the process completed, make sure that the cylinders and the equipment are removed from site promptly and all isolation valves on the equipment are closed off.
- Recovered refrigerant shall not be charged into another REFRIGERATING SYSTEM unless it has been cleaned and checked.

■ Labelling

Equipment shall be labelled stating that it has been de-commissioned and emptied of refrigerant. The label shall be dated and signed. For appliances containing FLAMMABLE REFRIGERANTS, ensure that there are labels on the equipment stating the equipment contains FLAMMABLE REFRIGERANT.

■ Recovery

When removing refrigerant from a system, either for servicing or decommissioning, it is recommended good practice that all refrigerants are removed safely.

When transferring refrigerant into cylinders, ensure that only appropriate refrigerant recovery cylinders are employed. Ensure that the correct number of cylinders for holding the total system charge is available.

All cylinders to be used are designated for the recovered refrigerant and labelled for that refrigerant (i.e., special cylinders for the recovery of refrigerant). Cylinders shall be complete with pressure-relief valve and associated shut-off valves in good working order.

Empty recovery cylinders are evacuated and, if possible, cooled before recovery occurs.

The recovery equipment shall be in good working order with a set of instructions concerning the equipment that is at hand and shall be suitable for the recovery of the flammable refrigerant.

If in doubt, the manufacturer should be consulted. In addition, a set of calibrated weighing scales shall be available and in good working order. Hoses shall be complete with leak-free disconnect couplings and in good condition.

The recovered refrigerant shall be processed according to local legislation in the correct recovery cylinder, and the relevant waste transfer note arranged. Do not mix refrigerants in recovery units and especially not in cylinders.

If compressors or compressor oils are to be removed, ensure that they have been evacuated to an acceptable level to make certain that FLAMMABLE REFRIGERANT does not remain within the lubricant.

The compressor body shall not be heated by an open flame or other ignition sources to accelerate this process. When oil is drained from a system, it shall be carried out safely.

MUZ-FX06NLHZ - ☐ U1

MUZ-FX09NLHZ - ☐ U1

MUZ-FX12NLHZ - ☐ U1


MUZ-FX15NLHZ - ☐ U1

MUZ-FX18NLHZ - ☐ U1


MUZ-FX24NLHZ - ☐ U1

1. New model

MUZ-FX06NLHZ
MUZ-FX09NLHZ
MUZ-FX12NLHZ



MUZ-FX15NLHZ
MUZ-FX18NLHZ
MUZ-FX24NLHZ



Outdoor unit model			MUZ-FX06NLHZ	MUZ-FX09NLHZ	MUZ-FX12NLHZ
Capacity Rated (Minimum–Maximum)	Cooling * ¹	Btu/h	6,000 (1,700–14,000)	9,000 (2,500–15,000)	12,000 (2,500–16,100)
	Heating 47 * ¹	Btu/h	9,000 (1,700–20,000)	12,000 (3,100–21,300)	13,200 (3,100–23,500)
Capacity Rated (Maximum)	Heating 17 * ²	Btu/h	6,000 (14,400)	7,700 (16,300)	9,300 (18,200)
Power consumption Rated (Minimum–Maximum)	Cooling * ¹	W	280 (120–1,240)	490 (160–1,580)	780 (160–1,660)
	Heating 47 * ¹	W	540 (120–1,770)	710 (180–2,130)	920 (180–2,140)
Power consumption Rated (Maximum)	Heating 17 * ²	W	510 (1,570)	650 (2,000)	800 (2,140)
EER2 * ¹ [SEER2] * ³	Cooling		21.45 [35.0]	18.35 [33.1]	15.40 [29.9]
HSPF2 Region IV * ⁴	Heating		13.0	13.3	12.4
COP	Heating		4.88	4.95	4.20
Power factor	Cooling	%	76	88	94
	Heating	%	90	93	95
Power supply	V, phase, Hz		208/230, 1, 60	208/230, 1, 60	208/230, 1, 60
Max. fuse size (time delay)		A	15	15	15
Min. circuit ampacity		A	12	14	14
Fan motor		A	0.76	0.76	0.76
Compressor	Model		SRB092FQFMT	SRB140FQHMT	SRB140FQHMT
	R.L.A	A	6.6	7.8	7.8
	L.R.A	A	8.2	9.8	9.8
	Refrigeration oil	fl oz. (L) (Model)	11.8 (0.35)/(RM68EH)	11.8 (0.35)/(RM68EH)	11.8 (0.35)/(RM68EH)
Refrigerant control			Linear expansion valve	Linear expansion valve	Linear expansion valve
Sound level * ¹	Cooling	dB(A)	47	49	49
	Heating	dB(A)	48	49	51
Airflow High–Med.–Low	Cooling	CFM	1,815–1,225–678	1,815–1,303–678	1,815–1,303–678
	Heating	CFM	1,321–1,225–678	1,321–1,321–678	1,321–1,321–678
Fan speed High–Med.–Low	Cooling	rpm	1,060–740–450	1,060–780–450	1,060–780–450
	Heating	rpm	790–740–450	790–790–450	790–790–450
Defrost method			Reverse cycle	Reverse cycle	Reverse cycle
Dimensions	W	in.	31-1/2	31-1/2	31-1/2
	D	in.	11-1/4	11-1/4	11-1/4
	H	in.	28-1/8	28-1/8	28-1/8
Weight		lb.	85	89	89
External finish			Munsell 3Y 7.8/1.1	Munsell 3Y 7.8/1.1	Munsell 3Y 7.8/1.1
Control voltage (by built-in transformer)		V DC	12–24	12–24	12–24
Refrigerant piping			Not supplied	Not supplied	Not supplied
Refrigerant pipe size (Min. wall thickness)	Liquid	in.	1/4	1/4	1/4
	Gas	in.	3/8	3/8	3/8
Connection method	Indoor		Flared	Flared	Flared
	Outdoor		Flared	Flared	Flared
Between the indoor & outdoor units	Height difference	ft.	40	40	40
	Piping length	ft.	65	65	65
Refrigerant charge (R454B)			2 lbs. 10 oz	2 lbs. 12 oz	2 lbs. 12 oz

NOTE: Test conditions are based on AHRI 210/240.

*1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°FWB, Outdoor: 95°FDB, (75°FWB)
(Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 47°FDB, 43°FWB

*2: Rating conditions (Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 17°FDB, 15°FWB

*3: Test condition (Refer to page 12.)

*4: Test condition (Refer to page 12.)

Outdoor unit model			MUZ-FX15NLHZ	MUZ-FX18NLHZ	MUZ-FX24NLHZ
Capacity Rated (Minimum–Maximum)	Cooling ^{*1}	Btu/h	15,000 (3,700–19,100)	17,200 (3,700–21,500)	20,800 (2,500–26,500)
	Heating 47 ^{*1}	Btu/h	16,500 (5,150–28,400)	17,000 (5,150–30,200)	19,800 (5,500–36,200)
Capacity Rated (Maximum)	Heating 17 ^{*2}	Btu/h	10,600 (26,500)	12,700 (28,200)	13,600 (29,200)
Power consumption Rated (Minimum–Maximum)	Cooling ^{*1}	W	1,020 (260–2,200)	1,320 (260–2,360)	1,560 (260–3,370)
	Heating 47 ^{*1}	W	1,080 (280–2,630)	1,390 (280–2,890)	1,500 (320–3,590)
Power consumption Rated (Maximum)	Heating 17 ^{*2}	W	1,010 (3,700)	1,240 (3,830)	1,320 (3,800)
EER2 ^{*1} [SEER2] ^{*3}	Cooling		14.70 [25.9]	13.05 [25.5]	13.35 [23.5]
HSPF2 Region IV ^{*4}	Heating		11.0	11.1	10.5
COP	Heating		4.47	3.58	3.86
Power factor	Cooling	%	100	97	98
	Heating	%	97	99	100
Power supply	V, phase, Hz		208/230, 1, 60	208/230, 1, 60	208/230, 1, 60
Max. fuse size (time delay)		A	20	20	20
Min. circuit ampacity		A	23	23	22
Fan motor		A	0.76	0.76	0.76
Compressor	Model		SRB172FQHMT	SRB172FQHMT	SRB220FQYMT
	R.L.A	A	13.6	13.6	13.1
	L.R.A	A	17	17	16.4
	Refrigeration oil	fl oz. (L) (Model)	14.5 (0.43)/(RM68EH)	14.5 (0.43)/(RM68EH)	15.6 (0.46)/(RM68EH)
Refrigerant control			Linear expansion valve	Linear expansion valve	Linear expansion valve
Sound level ^{*1}	Cooling	dB(A)	51	52	55
	Heating	dB(A)	55	55	55
Airflow High–Med.–Low	Cooling	CFM	2,204–1,773–978	2,204–1,773–978	2,204–2,204–1,391
	Heating	CFM	2,440–1,935–978	2,440–1,935–978	2,440–1,935–978
Fan speed High–Med.–Low	Cooling	rpm	900–740–450	900–740–450	900–900–600
	Heating	rpm	990–800–450	990–800–450	990–800–450
Defrost method			Reverse cycle	Reverse cycle	Reverse cycle
Dimensions	W	in.	33-1/16	33-1/16	33-1/16
	D	in.	13	13	13
	H	in.	34-5/8	34-5/8	34-5/8
Weight		lb.	119	119	122
External finish			Munsell 3Y 7.8/1.1	Munsell 3Y 7.8/1.1	Munsell 3Y 7.8/1.1
Control voltage (by built-in transformer)		V DC	12–24	12–24	12–24
Refrigerant piping			Not supplied	Not supplied	Not supplied
Refrigerant pipe size (Min. wall thickness)	Liquid	in.	1/4	1/4	1/4
	Gas	in.	1/2	1/2	5/8
Connection method	Indoor		Flared	Flared	Flared
	Outdoor		Flared	Flared	Flared
Between the indoor & outdoor units	Height difference	ft.	50	50	50
	Piping length	ft.	100	100	100
Refrigerant charge (R454B)			3 lbs. 7 oz	3 lbs. 7 oz	3 lbs. 6 oz

NOTE: Test conditions are based on AHRI 210/240.

*1: Rating conditions (Cooling) — Indoor: 80°FDB, 67°FWB, Outdoor: 95°FDB, (75°FWB)
(Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 47°FDB, 43°FWB

*2: Rating conditions (Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 17°FDB, 15°FWB

*3: Test condition (Refer to page 12.)

*4: Test condition (Refer to page 12.)

Test condition

*3, *4

AHRI 210/240	Mode	Test	Indoor air condition (°F)		Outdoor air condition (°F)	
			Dry bulb	Wet bulb	Dry bulb	Wet bulb
	SEER (Cooling)	"A-Full" Cooling Steady State at rated compressor speed	80	67	95	75
		"B-Full" Cooling Steady State at rated compressor speed	80	67	82	65
		"B-Low" Cooling Steady State at minimum compressor speed	80	67	82	65
		"F-Low" Cooling Steady State at minimum compressor speed	80	67	67	53.5
		"E-Int" Cooling Steady State at intermediate compressor speed *5	80	67	87	69
	HSPF (Heating)	"H1-Nom" Heating Steady State at rated compressor speed	70	60	47	43
		"H3-Full" Heating at rated compressor speed	70	60	17	15
		"H0-Low" Heating Steady State at minimum compressor speed	70	60	62	56.5
		"H1-Low" Heating Steady State at minimum compressor speed	70	60	47	43
		"H2-Int" Heating at intermediate compressor speed *5	70	60	35	33

*5: At intermediate compressor speed

= ("Rated compressor speed" - "minimum compressor speed") / 3 + "minimum compressor speed".

OPERATING RANGE

(1) POWER SUPPLY

	Rated voltage	Guaranteed voltage (V)
Outdoor unit	208/230 V 1 phase 60 Hz	Min. 187 208 230 Max. 253 ----- ----- ----- -----

(2) OPERATION

Mode	Condition	Intake air temperature (°F)	
		Outdoor	
		DB	WB
Cooling	Standard temperature	95	—
	Maximum temperature	115	—
	Minimum temperature	14	—
	Maximum humidity	—	
Heating	Standard temperature	47	43
	Maximum temperature	75	65
	Minimum temperature	- 22	- 23.8

OUTLINES AND DIMENSIONS


Unit: inch



MUZ-FX15NLHZ
MUZ-FX18NLHZ
MUZ-FX24NLHZ

Unit: inch

REQUIRED SPACE




MUZ-FX15/18NLHZ

REFRIGERANT PIPE JOINT	LIQUID REFRIGERANT PIPE	FLARED 1/4"
	GAS REFRIGERANT PIPE	FLARED 1/2"

MUZ-FX24NLHZ


REFRIGERANT PIPE JOINT	LIQUID REFRIGERANT PIPE	FLARED 1/4"
	GAS REFRIGERANT PIPE	FLARED 5/8"

MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ



SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CN61	CONNECTOR	LEV	EXPANSION VALVE COIL	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
C61, C62	SMOOTHING CAPACITOR	L61	REACTOR	TB1	TERMINAL BLOCK
DB61, DB65	DIODE MODULE	MC	COMPRESSOR	T801	TRANSFORMER
F61	FUSE (25A 250V)	MF	FAN MOTOR	PTC64, PTC65	CIRCUIT PROTECTION
F62	FUSE (15A 250V)	Q821	SWITCHING POWER TRANSISTOR	X63, X64, X66	RELAY
F701, F801, F901	FUSE (T3.15AL250V)	RT61	DEFROST THERMISTOR	21S4	REVERSING VALVE COIL
H	DEFROST HEATER	RT62	DISCHARGE TEMP. THERMISTOR	26C	COMPRESSOR PROTECTOR
IC700, IC932	POWER MODULE	RT64	FIN TEMP. THERMISTOR	26H	HEATER PROTECTOR
IC802	POWER DEVICE	RT65	AMBIENT TEMP. THERMISTOR		
LED	LED				


MUZ-FX15NLHZ MUZ-FX18NLHZ MUZ-FX24NLHZ




SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
CB1, CB2, CB3	SMOOTHING CAPACITOR	L	REACTOR	RT65	AMBIENT TEMP. THERMISTOR
CN61	CONNECTOR	LED	LED	RT68	OUTDOOR HEAT EXCHANGER TEMP. THERMISTOR
DB41	DIODE MODULE	LEV	EXPANSION VALVE COIL	TB1	TERMINAL BLOCK
D3A, D3B	DIODE	MC	COMPRESSOR	T801	TRANSFORMER
F61	FUSE (25A 250V)	MF	FAN MOTOR	PTC64, PTC65	CIRCUIT PROTECTION
F62	FUSE (15A 250V)	Q3A, Q3B	SWITCHING POWER TRANSISTOR	X64, X601, X602	RELAY
F65, F66	FUSE (T6.3AL250V)	RT61	DEFROST TEMP. THERMISTOR	21S4	REVERSING VALVE COIL
F601, F880, F901	FUSE (T3.15AL250V)	RT62	DISCHARGE TEMP. THERMISTOR	26C	COMPRESSOR PROTECTOR
H	DEFROST HEATER	RT64	FIN TEMP. THERMISTOR	26H	HEATER PROTECTOR
IC700, IC932	POWER MODULE				

MUZ-FX06NLHZ
MUZ-FX09NLHZ
MUZ-FX12NLHZ

Unit: Inch (mm)




MUZ-FX15NLHZ
MUZ-FX18NLHZ
MUZ-FX24NLHZ



MAX. REFRIGERANT PIPING LENGTH and MAX. HEIGHT DIFFERENCE

Model	Refrigerant piping: ft.		Piping size O.D: in.	
	Max. Length A	Max. Height difference B	Gas	Liquid
MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ	65	40	3/8	1/4
MUZ-FX15NLHZ MUZ-FX18NLHZ	100	50	1/2	1/4
MUZ-FX24NLHZ	100	50	5/8	1/4



ADDITIONAL REFRIGERANT CHARGE (R454B: oz.)

NOTE: Refrigerant piping exceeding 25 ft. requires additional refrigerant charge according to the calculation.

Model	Outdoor unit precharged	Refrigerant piping length (one way): ft.					
		25	30	40	50	60	65
MUZ-FX06NLHZ	2 lbs. 10 oz	0	1.1	3.3	5.5	7.7	8.8
MUZ-FX09NLHZ	2 lbs. 12 oz						
MUZ-FX12NLHZ							

Calculation: X oz. = 0.22 oz./ft. × (Refrigerant piping length (ft.) - 25)

NOTE: Refrigerant piping exceeding 50 ft. requires additional refrigerant charge according to the calculation.

Model	Outdoor unit precharged	Refrigerant piping length (one way): ft.									
		25	30	40	50	60	65	70	80	90	100
MUZ-FX15NLHZ	3 lbs. 7 oz	0	0	0	0	2.2	3.3	4.4	6.6	8.8	11
MUZ-FX18NLHZ											
MUZ-FX24NLHZ	3 lbs. 6 oz										

Calculation: X oz. = 0.22 oz./ft. × (Refrigerant piping length (ft.) - 50)

MUZ-FX06NLHZ MUZ-FX09NLHZ
MUZ-FX12NLHZ MUZ-FX15NLHZ
MUZ-FX18NLHZ MUZ-FX24NLHZ

7-1. PERFORMANCE DATA

1) COOLING CAPACITY

Model	Indoor air	Outdoor intake air DB temperature (°F)											
	IWB (°F)	75				85				95			
		TC	SHC	SHF	TPC	TC	SHC	SHF	TPC	TC	SHC	SHF	TPC
MUZ-FX06NLHZ	71	7.4	6.4	0.87	0.25	6.9	6.0	0.87	0.27	6.5	5.6	0.87	0.29
	67	7.0	7.0	1.00	0.24	6.5	6.5	1.00	0.26	6.0	6.0	1.00	0.28
	63	6.5	6.5	1.00	0.22	6.1	6.1	1.00	0.25	5.6	5.6	1.00	0.27
MUZ-FX09NLHZ	71	11.0	9.6	0.87	0.44	10.3	8.9	0.87	0.48	9.7	8.4	0.87	0.51
	67	10.4	10.4	1.00	0.41	9.7	9.7	1.00	0.45	9.0	9.0	1.00	0.49
	63	9.8	9.8	1.00	0.39	9.1	9.1	1.00	0.43	8.5	8.5	1.00	0.47
MUZ-FX12NLHZ	71	14.7	11.0	0.75	0.69	13.7	10.3	0.75	0.76	12.9	9.6	0.75	0.82
	67	13.9	12.2	0.88	0.66	13.0	11.4	0.88	0.72	12.0	10.6	0.88	0.78
	63	13.1	13.1	1.00	0.62	12.1	12.1	1.00	0.69	11.3	11.3	1.00	0.74
MUZ-FX15NLHZ	71	18.4	12.4	0.68	0.91	17.2	11.6	0.68	0.99	16.1	10.9	0.68	1.07
	67	17.4	14.1	0.81	0.86	16.2	13.1	0.81	0.94	15.0	12.2	0.81	1.02
	63	16.4	15.4	0.94	0.82	15.2	14.3	0.94	0.90	14.1	13.3	0.94	0.97
MUZ-FX18NLHZ	71	21.1	13.2	0.63	1.17	19.7	12.3	0.63	1.29	18.5	11.6	0.63	1.39
	67	20.0	15.2	0.76	1.11	18.6	14.1	0.76	1.22	17.2	13.1	0.76	1.32
	63	18.7	16.7	0.89	1.06	17.4	15.5	0.89	1.17	16.2	14.4	0.89	1.26
MUZ-FX24NLHZ	71	25.5	16.5	0.65	1.39	23.8	15.4	0.65	1.52	22.4	14.5	0.65	1.64
	67	24.1	18.8	0.78	1.31	22.5	17.5	0.78	1.44	20.8	16.2	0.78	1.56
	63	22.7	20.7	0.91	1.25	21.0	19.2	0.91	1.38	19.6	17.9	0.91	1.49

Model	Indoor air IWB (°F)	Outdoor intake air DB temperature (°F)							
		105				115			
		TC	SHC	SHF	TPC	TC	SHC	SHF	TPC
MUZ-FX06NLHZ	71	6.0	5.2	0.87	0.31	5.5	4.8	0.87	0.32
	67	5.6	5.6	1.00	0.30	5.1	5.1	1.00	0.31
	63	5.1	5.1	1.00	0.29	4.7	4.7	1.00	0.30
MUZ-FX09NLHZ	71	9.0	7.8	0.87	0.54	8.3	7.2	0.87	0.56
	67	8.4	8.4	1.00	0.52	7.7	7.7	1.00	0.54
	63	7.7	7.7	1.00	0.50	7.0	7.0	1.00	0.52
MUZ-FX12NLHZ	71	12.0	9.0	0.75	0.86	11.0	8.2	0.75	0.90
	67	11.2	9.8	0.88	0.83	10.3	9.0	0.88	0.87
	63	10.3	10.3	1.00	0.80	9.4	9.4	1.00	0.83
MUZ-FX15NLHZ	71	15.0	10.2	0.68	1.13	13.8	9.3	0.68	1.17
	67	14.0	11.3	0.81	1.08	12.8	10.4	0.81	1.13
	63	12.8	12.1	0.94	1.04	11.7	11.0	0.94	1.08
MUZ-FX18NLHZ	71	17.2	10.8	0.63	1.46	15.8	9.9	0.63	1.52
	67	16.0	12.2	0.76	1.40	14.7	11.2	0.76	1.47
	63	14.7	13.1	0.89	1.35	13.4	12.0	0.89	1.40
MUZ-FX24NLHZ	71	20.8	13.5	0.65	1.72	19.1	12.4	0.65	1.79
	67	19.3	15.1	0.78	1.65	17.8	13.9	0.78	1.73
	63	17.8	16.2	0.91	1.59	16.2	14.8	0.91	1.65

NOTE: 1. IWB : Intake air wet-bulb temperature TC : Total Capacity ($\times 10^3$ Btu/h)
 SHC : Sensible Heat Capacity ($\times 10^3$ Btu/h) SHF : Sensible Heat Factor
 TPC : Total Power Consumption (kW)
 2. SHC is based on 80°F of indoor Intake air DB temperature.
 3. Data shown are estimated value. Performance may vary depending on operating conditions.

2) COOLING CAPACITY CORRECTIONS

Refrigerant piping length (one way: ft.)				
	25 (std.)	40	65	100
MUZ-FX06NLHZ	1.0	0.997	0.992	—
MUZ-FX09NLHZ		0.993	0.981	—
MUZ-FX12NLHZ		0.987	0.967	—
MUZ-FX15NLHZ		0.996	0.988	0.978
MUZ-FX18NLHZ		0.994	0.983	0.969
MUZ-FX24NLHZ		0.996	0.99	0.982

3) HEATING CAPACITY CORRECTIONS

Refrigerant piping length (one way: ft.)				
	25 (std.)	40	65	100
MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ	1.0	0.997	0.993	—
MUZ-FX15NLHZ MUZ-FX18NLHZ MUZ-FX24NLHZ	1.0	0.997	0.993	0.987

4) HEATING CAPACITY

Model	Indoor air IDB (°F)	Outdoor intake air WB temperature (°F)													
		5		15		25		35		43		45		55	
		TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC	TC	TPC
MUZ-FX06NLHZ	75	4.0	0.32	5.2	0.40	6.5	0.47	7.8	0.53	8.8	0.55	9.0	0.56	10.3	0.58
	70	4.3	0.31	5.5	0.39	6.8	0.46	8.0	0.51	9.0	0.54	9.3	0.55	10.5	0.57
	65	4.5	0.29	5.7	0.37	7.1	0.45	8.2	0.50	9.3	0.53	9.5	0.53	10.7	0.56
MUZ-FX09NLHZ	75	5.3	0.42	7.0	0.53	8.7	0.62	10.4	0.69	11.7	0.73	12.1	0.74	13.7	0.77
	70	5.7	0.40	7.4	0.51	9.0	0.61	10.6	0.67	12.0	0.71	12.4	0.72	14.0	0.75
	65	6.0	0.38	7.6	0.49	9.4	0.59	11.0	0.66	12.4	0.69	12.7	0.70	14.3	0.74
MUZ-FX12NLHZ	75	5.8	0.54	7.7	0.69	9.6	0.81	11.4	0.90	12.9	0.94	13.3	0.96	15.0	0.99
	70	6.3	0.52	8.1	0.66	9.9	0.79	11.7	0.87	13.2	0.92	13.6	0.94	15.4	0.98
	65	6.6	0.50	8.3	0.63	10.4	0.76	12.1	0.85	13.6	0.90	14.0	0.91	15.7	0.96
MUZ-FX15NLHZ	75	7.3	0.64	9.6	0.80	12.0	0.95	14.3	1.05	16.1	1.11	16.6	1.12	18.8	1.17
	70	7.8	0.61	10.1	0.78	12.4	0.92	14.6	1.03	16.5	1.08	17.0	1.10	19.2	1.14
	65	8.3	0.58	10.4	0.75	13.0	0.89	15.1	1.00	17.0	1.05	17.5	1.07	19.6	1.12
MUZ-FX18NLHZ	75	7.5	0.82	9.9	1.04	12.3	1.22	14.7	1.36	16.6	1.42	17.1	1.45	19.4	1.50
	70	8.1	0.79	10.5	1.00	12.8	1.19	15.0	1.32	17.0	1.39	17.5	1.42	19.8	1.47
	65	8.5	0.75	10.7	0.96	13.3	1.15	15.6	1.29	17.5	1.36	18.0	1.38	20.2	1.45
MUZ-FX24NLHZ	75	8.7	0.89	11.5	1.12	14.4	1.31	17.1	1.46	19.3	1.54	19.9	1.56	22.6	1.62
	70	9.4	0.85	12.2	1.08	14.9	1.28	17.5	1.43	19.8	1.50	20.4	1.53	23.1	1.59
	65	9.9	0.81	12.5	1.04	15.5	1.24	18.1	1.39	20.4	1.46	21.0	1.49	23.6	1.56

NOTE: 1. IDB : Intake air dry-bulb temperature

TC : Total Capacity (x10³ Btu/h)

TPC : Total Power Consumption (kW)

2. Above data is for heating operation without any frost.


3. Data shown are estimated value. Performance may vary depending on operating conditions.

How to operate with fixed operational frequency of the compressor.


1. Press the emergency operation switch on the front of the indoor unit, and select either EMERGENCY COOL mode or EMERGENCY HEAT mode before starting to operate the air conditioner.
2. The compressor starts with operational frequency.
3. The fan speed of the indoor unit is High.
4. This operation continues for 30 minutes.
5. In order to release this operation, press the emergency operation switch twice or once, or press any button on the remote controller.

7-2. PERFORMANCE CURVE


Cooling (at Rated frequency)




MUZ-FX06NLHZ




MUZ-FX09NLHZ




MUZ-FX12NLHZ




MUZ-FX15NLHZ



MUZ-FX18NLHZ




MUZ-FX24NLHZ




This value of frequency is not the same as the actual frequency in operating. Refer to 7-5 and 7-6 for the relationships between frequency and capacity.

NOTE: Data shown are estimated value. Performance may vary depending on operating conditions.


Heating (at Rated frequency)




MUZ-FX06NLHZ




MUZ-FX09NLHZ




MUZ-FX12NLHZ




MUZ-FX15NLHZ



MUZ-FX18NLHZ



MUZ-FX24NLHZ



This value of frequency is not the same as the actual frequency in operating. Refer to 7-5 and 7-6 for the relationships between frequency and capacity.

NOTE: Data shown are estimated value. Performance may vary depending on operating conditions.


7-3. CONDENSING PRESSURE

Cooling


Data are based on the condition of indoor humidity 50 %.

Air flow should be set to High speed.


MUZ-FX06NLHZ




MUZ-FX09NLHZ




MUZ-FX12NLHZ




MUZ-FX15NLHZ



MUZ-FX18NLHZ



MUZ-FX24NLHZ



NOTE: Data shown are estimated value. Performance may vary depending on operating conditions.



Heating

Data are based on the condition of outdoor humidity 75%.



Air flow should be set to High speed.

Data are for heating operation without any frost.



MUZ-FX06NLHZ




MUZ-FX09NLHZ




MUZ-FX12NLHZ




MUZ-FX15NLHZ



MUZ-FX18NLHZ



MUZ-FX24NLHZ




- NOTE:**
1. Press the emergency operation switch on the front of the indoor unit, and select either EMERGENCY COOL mode or EMERGENCY HEAT mode before starting to operate the air conditioner.
 2. The compressor starts with operational frequency.
 3. The fan speed of the indoor unit is High.
 4. This operation continues for 30 minutes.
 5. In order to release this operation, press the emergency operation switch twice or once, or press any button on the remote controller.
 6. Data shown are estimated value. Performance may vary depending on operating conditions.

7-4. STANDARD OPERATION DATA


Model				MSZ-FX06NL	
Item			Unit	COOL	HEAT
Total	Capacity		Btu/h	6,000	9,000
	SHF		—	1.00	—
	Input		kW	0.28	0.54
	Rated frequency		Hz	28	53
Electrical circuit	Indoor unit			MSZ-FX06NL	
	Power supply		V, phase, Hz	208/230, 1 , 60	
	Input		kW	0.014	0.019
	Fan motor current		A	0.17/0.15	0.21/0.19
	Outdoor unit			MUZ-FX06NLHZ	
	Power supply		V, phase, Hz	208/230, 1, 60	
	Input		kW	0.266	0.521
	Comp. current		A	1.41/1.25	2.47/2.21
	Fan motor current		A	0.22/0.20	0.22/0.20
Refrigerant circuit	Condensing pressure		psig	314	284
	Suction pressure		psig	170	106
	Discharge temperature		°F	135	135
	Condensing temperature		°F	103	39
	Suction temperature		°F	71	39
	Comp. shell bottom temperature		°F	—	
	Ref. pipe length		ft.	25	
	Refrigerant charge (R454B)			2 lbs. 10 oz	
Indoor unit	Intake air temperature	DB	°F	80	70
		WB	°F	67	60
	Discharge air temperature	DB	°F	66	91
		WB	°F	65	—
	Fan speed (High)		rpm	820	900
	Airflow (High)		CFM	357 (wet)	477
Outdoor unit	Intake air temperature	DB	°F	95	47
		WB	°F	—	43
	Fan speed		rpm	740	
	Airflow		CFM	1,225	




Model			MSZ-FX09NL	
Item		Unit	COOL	HEAT
Total	Capacity	Btu/h	9,000	12,000
	SHF	—	1.00	—
	Input	kW	0.49	0.71
	Rated frequency	Hz	29.5	45
Electrical circuit	Indoor unit		MSZ-FX09NL	
	Power supply	V, phase, Hz	208/230, 1, 60	
	Input	kW	0.024	0.019
	Fan motor current	A	0.27/0.24	0.21/0.19
	Outdoor unit		MUZ-FX09NLHZ	
	Power supply	V, phase, Hz	208/230, 1, 60	
	Input	kW	0.466	0.691
	Comp. current	A	2.18/1.94	3.14/2.88
	Fan motor current	A	0.25/0.22	0.25/0.23
Refrigerant circuit	Condensing pressure	psig	329	301
	Suction pressure	psig	155	103
	Discharge temperature	°F	140	137
	Condensing temperature	°F	106	37
	Suction temperature	°F	60	37
	Comp. shell bottom temperature	°F	—	
	Ref. pipe length	ft.	25	
	Refrigerant charge (R454B)		2 lbs.12 oz	
Indoor unit	Intake air temperature	DB	°F	80
		WB	°F	67
	Discharge air temperature	DB	°F	64
		WB	°F	63
	Fan speed (High)	rpm		970
	Airflow (High)	CFM		447 (wet)
Outdoor unit	Intake air temperature	DB	°F	95
		WB	°F	—
	Fan speed	rpm		780
	Airflow	CFM		1,303




Model				MSZ-FX12NL	
Item			Unit	COOL	HEAT
Total	Capacity		Btu/h	12,000	13,200
	SHF		—	0.88	—
	Input		kW	0.78	0.92
	Rated frequency		Hz	44.5	54.5
Electrical circuit	Indoor unit			MSZ-FX12NL	
	Power supply V, phase, Hz			208/230, 1, 60	
	Input		kW	0.024	0.019
	Fan motor current		A	0.27/0.24	0.21/0.19
	Outdoor unit			MUZ-FX12NLHZ	
	Power supply V, phase, Hz			208/230, 1, 60	
	Input		kW	0.76	0.901
	Comp. current		A	3.48/3.14	4.14/3.78
	Fan motor current		A	0.25/0.22	0.25/0.23
Refrigerant circuit	Condensing pressure		psig	349	324
	Suction pressure		psig	135	101
	Discharge temperature		°F	153	146
	Condensing temperature		°F	111	37
	Suction temperature		°F	52	36
	Comp. shell bottom temperature		°F	—	
	Ref. pipe length		ft.	25	
	Refrigerant charge (R454B)			2 lbs. 12 oz	
Indoor unit	Intake air temperature	DB	°F	80	70
		WB	°F	67	60
	Discharge air temperature	DB	°F	60	101
		WB	°F	59	—
	Fan speed (High)		rpm	970	900
	Airflow (High)		CFM	447 (wet)	477
Outdoor unit	Intake air temperature	DB	°F	95	47
		WB	°F	—	43
	Fan speed		rpm	780	790
	Airflow		CFM	1,303	1,321



Model			MSZ-FX15NL	
Item		Unit	COOL	HEAT
Total	Capacity	Btu/h	15,000	16,500
	SHF	—	0.81	—
	Input	kW	1.02	1.08
	Rated frequency	Hz	47	48
Electrical circuit	Indoor unit		MSZ-FX15NL	
	Power supply	V, phase, Hz	208/230, 1, 60	
	Input	kW	0.033	0.036
	Fan motor current	A	0.34/0.31	0.36/0.33
	Outdoor unit		MUZ-FX15NLHZ	
	Power supply	V, phase, Hz	208/230, 1, 60	
	Input	kW	0.987	1.044
	Comp. current	A	3.8/3.41	4.06/3.68
	Fan motor current	A	0.76/0.68	0.86/0.78
Refrigerant circuit	Condensing pressure	psig	339	331
	Suction pressure	psig	132	106
	Discharge temperature	°F	157	152
	Condensing temperature	°F	108	38
	Suction temperature	°F	56	39
	Comp. shell bottom temperature	°F	—	
	Ref. pipe length	ft.	25	
	Refrigerant charge (R454B)		3 lbs.7 oz	
Indoor unit	Intake air temperature	DB	°F	80
		WB	°F	70
	Discharge air temperature	DB	°F	67
		WB	°F	60
	Fan speed (High)	rpm		59
Outdoor unit	Intake air temperature	DB	°F	99
		WB	°F	58
	Fan speed	rpm		—
	Airflow (High)	CFM		1,060
		CFM		504 (wet)
Outdoor unit	Intake air temperature	DB	°F	1,090
		WB	°F	614
	Fan speed	rpm		740
	Airflow	CFM		1,773




Model				MSZ-FX18NL	
Item			Unit	COOL	HEAT
Total	Capacity		Btu/h	17,200	17,000
	SHF		—	0.76	—
	Input		kW	1.32	1.39
	Rated frequency		Hz	59	58
Electrical circuit	Indoor unit			MSZ-FX18NL	
	Power supply	V, phase, Hz		208/230, 1, 60	
	Input		kW	0.033	0.036
	Fan motor current		A	0.34/0.31	0.36/0.33
	Outdoor unit			MUZ-FX18NLHZ	
	Power supply	V, phase, Hz		208/230, 1, 60	
	Input		kW	1.287	1.354
	Comp. current		A	5.4/4.91	5.48/4.99
Refrigerant circuit	Fan motor current		A	0.76/0.68	0.86/0.78
	Condensing pressure		psig	349	359
	Suction pressure		psig	120	104
	Discharge temperature		°F	162	159
	Condensing temperature		°F	110	37
	Suction temperature		°F	48	37
	Comp. shell bottom temperature		°F	—	
	Ref. pipe length		ft.	25	
Indoor unit	Refrigerant charge (R454B)			3 lbs. 7 oz	
	Intake air temperature	DB	°F	80	70
		WB	°F	67	60
	Discharge air temperature	DB	°F	57	104
		WB	°F	56	—
	Fan speed (High)		rpm	1,060	1,090
	Airflow (High)		CFM	504 (wet)	614
Outdoor unit	Intake air temperature	DB	°F	95	47
		WB	°F	—	43
	Fan speed		rpm	740	800
	Airflow		CFM	1,773	1,935




Model			MSZ-FX24NL	
Item		Unit	COOL	HEAT
Total	Capacity	Btu/h	20,800	19,800
	SHF	—	0.78	—
	Input	kW	1.56	1.50
	Rated frequency	Hz	52.5	48.5
Electrical circuit	Indoor unit		MSZ-FX24NL	
	Power supply	V, phase, Hz	208/230, 1, 60	
	Input	kW	0.056	0.064
	Fan motor current	A	0.53/0.48	0.59/0.53
	Outdoor unit		MUZ-FX24NLHZ	
	Power supply	V, phase, Hz	208/230, 1, 60	
	Input	kW	1.504	1.437
	Comp. current	A	5.97/5.42	5.75/5.19
	Fan motor current	A	1.1/1	0.86/0.78
Refrigerant circuit	Condensing pressure	psig	345	336
	Suction pressure	psig	124	101
	Discharge temperature	°F	161	157
	Condensing temperature	°F	110	37
	Suction temperature	°F	52	37
	Comp. shell bottom temperature	°F	—	
	Ref. pipe length	ft.	25	
	Refrigerant charge (R454B)		3 lbs. 6 oz	
Indoor unit	Intake air temperature	DB	°F	80
		WB	°F	67
	Discharge air temperature	DB	°F	61
		WB	°F	60
	Fan speed (High)	rpm		1,230
Outdoor unit	Airflow (High)	CFM		612 (wet)
	Intake air temperature	DB	°F	95
		WB	°F	V
	Fan speed	rpm		900
	Airflow	CFM		2,204

7-5. CAPACITY AND INPUT CORRECTION BY INVERTER OUTPUT FREQUENCY


MUZ-FX06NLHZ




MUZ-FX09NLHZ




MUZ-FX12NLHZ




MUZ-FX15NLHZ



MUZ-FX18NLHZ



MUZ-FX24NLHZ



NOTE: 1. Data shown are estimated value. Performance may vary depending on operating conditions.

2. Conditions are based on AHRI 210/240.

Rating conditions (Cooling) — Indoor: 80°FDB, 67°FWB, Outdoor: 95°FDB, (75°FWB)

(Heating) — Indoor: 70°FDB, 60°FWB, Outdoor: 47°FDB, 43°FWB

7-6. HOW TO OPERATE FIXED-FREQUENCY OPERATION (Test run operation)

1. Press the emergency operation switch to start COOL or HEAT mode (COOL: Press once, HEAT: Press twice).
2. Test run operation starts and continues to operate for 30 minutes.
3. Compressor operates at rated frequency in COOL mode or 58 Hz in HEAT mode.
4. Indoor fan operates at High speed.
5. After 30 minutes, test run operation finishes and EMERGENCY OPERATION starts (operation frequency of compressor varies).
6. To cancel test run operation (EMERGENCY OPERATION), press the emergency operation switch or any button on remote controller.


MUZ-FX06NLHZ MUZ-FX09NLHZ
MUZ-FX12NLHZ MUZ-FX15NLHZ
MUZ-FX18NLHZ MUZ-FX24NLHZ

8-1. OUTDOOR FAN MOTOR CONTROL

The fan motor turns ON/OFF, interlocking with the compressor.

[ON] The fan motor turns ON 5 seconds before the compressor starts up.

[OFF] The fan motor turns OFF 15 seconds after the compressor has stopped running.




8-2. R.V. COIL CONTROL

Heating ON

Cooling OFF

Dry OFF

NOTE: The 4-way valve reverses for 5 seconds right before startup of the compressor.



8-3. RELATION BETWEEN MAIN SENSOR AND ACTUATOR

Sensor	Purpose	Actuator					
		Compressor	LEV	Outdoor fan motor	R.V.coil	Indoor fan motor	Defrost heater
Discharge temperature thermistor	Protection	○	○				
Indoor coil temperature thermistor	Cooling: Coil frost prevention	○					
	Heating: High pressure protection	○	○				
Defrost thermistor	Heating: Defrosting	○	○	○	○	○	
Fin temperature thermistor	Protection	○		○			
Ambient temperature thermistor	Cooling: Low ambient temperature operation	○	○	○			
	Heating: Defrosting (Heater)						○
Outdoor heat exchanger temperature thermistor	Cooling: Low ambient temperature operation	○	○	○			
	Cooling: High pressure protection	○	○	○			

MUZ-FX06NLHZ MUZ-FX09NLHZ
MUZ-FX12NLHZ MUZ-FX15NLHZ
MUZ-FX18NLHZ MUZ-FX24NLHZ

9-1. CHANGE IN DEFROST SETTING

Changing defrost finish temperature

<JS> To change the defrost finish temperature, cut/solder the JS wire of the outdoor inverter P.C. board (Refer to 10-6.1.).

Jumper		Defrost finish temperature	
		MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ	MUZ-FX15NLHZ MUZ-FX18NLHZ MUZ-FX24NLHZ
JS	Soldered (Initial setting)	46.4°F (8°C)	50°F (10°C)
	None (Cut)	55.4°F (13°C)	59°F (15°C)

9-2. PRE-HEAT CONTROL SETTING

Prolonged low load operation, in which the thermostat is OFF for a long time, at low outside temperature [32°F (0°C) or less] may cause the following troubles. To prevent those troubles, activate the pre-heat control.

- 1) If moisture gets into the refrigerant cycle and freezes, it may interfere the startup of the compressor.
- 2) If liquid refrigerant collects in the compressor, a failure in the compressor may occur.

The pre-heat control turns ON when the compressor temperature is 68°F (20°C) or below. When the pre-heat control turns ON, the compressor is energized. (About 70 W)

Pre-heat control setting

<JK>

ON: To activate the pre-heat control, cut JK wire of the inverter P.C. board.

OFF: To deactivate the pre-heat control, solder JK wire of the inverter P.C. board.

(Refer to 10-6.1)

Jumper		Pre-heat control setting
JK	Soldered	Deactivated (Initial setting)
	Cut	Activated

NOTE: When the inverter P.C. board is replaced, check the jumper wires, and cut/solder them if necessary.

MUZ-FX06NLHZ MUZ-FX09NLHZ
MUZ-FX12NLHZ MUZ-FX15NLHZ
MUZ-FX18NLHZ MUZ-FX24NLHZ

10-1. CAUTIONS ON TROUBLESHOOTING


1. Before troubleshooting, check the following

- 1) Check the power supply voltage.
- 2) Check the indoor/outdoor connecting wire for miswiring.

2. Take care of the following during servicing

- 1) Before servicing the air conditioner, be sure to turn OFF the main unit first with the remote controller, then after confirming the horizontal vane is closed, turn off the breaker and/or disconnect the power plug.
- 2) Be sure to turn OFF the power supply before removing the front panel, the cabinet, the top panel, and the electronic control P.C. board.
- 3) When removing the electrical parts, be careful of the residual voltage of smoothing capacitor.
- 4) When removing the electronic control P.C. board, hold the edge of the board with care NOT to apply stress on the components.
- 5) When connecting or disconnecting the connectors, hold the connector housing. DO NOT pull the lead wires.

<Incorrect>



Lead wiring

<Correct>



Connector housing

3. Troubleshooting procedure

- 1) Check if the OPERATION INDICATOR lamp on the indoor unit is blinking on and off to indicate an abnormality.
To make sure, check how many times the OPERATION INDICATOR lamp is blinking on and off before starting service work.
- 2) Before servicing, verify that all connectors and terminals are connected properly.
- 3) When the electronic control P.C. board seems to be defective, check for disconnection of the copper foil pattern and burnt or discolored components.
- 4) Refer to 10-2 and 10-3.

10-2. FAILURE MODE RECALL FUNCTION AND ERROR CODE DISPLAY MODE

Outline of the function


This air conditioner can memorize the failure which has occurred last time.


Even though LED indication listed on the troubleshooting check table (10-3.) disappears, the memorized failure can be recalled.

Also, error code can be checked on the display of remote controller while the left operation indicator lamp on the indoor unit is blinking.

1. Flow chart of failure mode recall function for the indoor/outdoor unit

Operational procedure







NOTE: 1. Make sure to release the failure mode recall function after it is set up, otherwise the unit cannot operate properly.
2. If the abnormal condition is not deleted from the memory, the last abnormal condition is kept memorized.

*1. Regardless of normal or abnormal condition, 2 short beeps are emitted once the signal is received.

*2. Blinking pattern when the indoor unit is abnormal:



*3. Blinking pattern when the outdoor unit is abnormal:



2. Flow chart of the outdoor unit failure mode recall function

Operational procedure

The outdoor unit might be abnormal.
Check if the outdoor unit is abnormal according to the following procedures.

Make sure that the remote controller is set to the failure mode recall function.

Get close to the front of the indoor unit. With the remote controller headed towards the indoor unit, press  button to set the indicator shown in Figure 1 to 25. *1 (Figure 1)







Figure 1






NOTE: 1. Make sure to release the failure mode recall function after it is set up, otherwise the unit cannot operate properly.
2. If the abnormal condition is not deleted from the memory, the last abnormal condition is kept memorized.

*1. Regardless of normal or abnormal condition, 2 short beeps are emitted once the signal is received.


*2. Blinking pattern when outdoor unit is abnormal:



3. Flow chart of error code display mode

This explains how customers can check the error code on their own.
This is included in OPERATING INSTRUCTIONS.

Operational procedure



4. Table of outdoor unit failure mode recall function

OPERATION INDICATOR lamp (Indoor unit)	Error code	Abnormal point (Failure mode/protection)	LED indication (Outdoor P.C. board)	Condition	Remedy	Indoor/outdoor unit failure mode recall function	Outdoor unit failure mode recall function	
Not blink	00	None (Normal)	—	—	—	—	—	
1-time blink 2.5 seconds OFF	E8	Indoor/outdoor communication, receiving error	—	Any signals from the inverter P.C. board cannot be received normally for 3 minutes.	• Refer to 10-5.㉔ “How to check miswiring and serial signal error”.	○	○	
	E9	Indoor/outdoor communication, receiving error	—	Although the inverter P.C. board sends signal “0”, signal “1” has been received 30 consecutive times.	• Refer to 10-5.㉔ “How to check miswiring and serial signal error”.			
	EC	Indoor/outdoor communication, start-up process abnormality	—	The start-up process of the outdoor unit does not complete for 4 minutes.	• Replace the indoor electronic control P.C. board.			
2-time blink 2.5 seconds OFF	UP	Outdoor power system	—	Overcurrent protection cut-out operates 3 consecutive times within 1 minute after the compressor gets started.	• Reconnect connectors. • Refer to 10-5.㉕ “How to check inverter/ compressor”. • Check stop valve.	○	○	
3-time blink 2.5 seconds OFF	U3	Discharge temperature thermistor	1-time blink every 2.5 seconds	Thermistor shorts or opens during compressor running.	• Refer to 10-5.㉖ “Check of outdoor thermistors”. Defective outdoor thermistors can be identified by checking the blinking pattern of LED.	○	○	
	U4	Defrost thermistor	2-time blink 2.5 seconds OFF					
		Ambient temperature						2-time blink 2.5 seconds OFF
		Fin temperature thermistor						3-time blink 2.5 seconds OFF
		Outdoor heat exchanger temperature thermistor	—		• Replace the inverter P.C. board.			
P.C. board temperature thermistor	4-time blink 2.5 seconds OFF							
4-time blink 2.5 seconds OFF	UF	Overcurrent	11-time blink 2.5 seconds OFF	Large current flows into power module (IC700).	• Reconnect compressor connector. • Refer to 10-5.㉗ “How to check inverter/ compressor”. • Check stop valve.	—	○	
		Compressor synchronous abnormality	12-time blink 2.5 seconds OFF	Waveform of compressor current is distorted.	• Reconnect compressor connector.	—	○	
		Compressor start-up failure protection	13-time blink 2.5 seconds OFF	Overcurrent cutoff within 10 seconds after activating the compressor.	• Refer to 10-5.㉗ “How to check inverter/ compressor”.	—	○	
5-time blink 2.5 seconds OFF	U2	Discharge temperature	—	Temperature of discharge temperature thermistor exceeds 241°F (116°C), compressor stops. Compressor can restart if discharge temperature thermistor reads 212°F (100°C) or less 3 minutes later.	• Check refrigerant circuit and refrigerant amount. • Refer to 10-5.㉘ “Check of LEV”.	—	○	
6-time blink 2.5 seconds OFF	Ud	High pressure	—	Temperature of outdoor heat exchanger temperature thermistor exceeds 158°F (70°C) in COOL mode.	• Check refrigerant circuit and refrigerant amount. • Check stop valve.	—	○	
7-time blink 2.5 seconds OFF	U5	Fin temperature	7-time blink 2.5 seconds OFF	Temperature of fin temperature thermistor on the inverter P.C. board exceeds 167 - 187°F (75 - 86°C), or temperature of P.C. board temperature thermistor on the inverter P.C. board exceeds 162 - 185°F (72 - 85°C).	• Check around outdoor unit. • Check outdoor unit air passage. • Refer to 10-5.㉙ “Check of outdoor fan motor”.	—	○	
	Ub	P.C. board temperature						
8-time blink 2.5 seconds OFF	U8	Outdoor fan motor	—	Outdoor fan has stopped 3 times in a row within 30 seconds after outdoor fan start-up.	• Refer to 10-5.㉙ “Check of outdoor fan motor”. Refer to 10-5.㉙ “Check of inverter P.C. board”.	—	○	

NOTE: Blinking patterns of this mode differ from the ones of TROUBLESHOOTING CHECK TABLE (10-3.).

NOTE: Blinking patterns of this mode differ from the ones of TROUBLESHOOTING CHECK TABLE (10-3.).

OPERATION INDICATOR lamp (Indoor unit)	Error code	Abnormal point (Failure mode/protection)	LED indication (Outdoor P.C. board)	Condition	Remedy	Indoor/outdoor unit failure mode recall function	Outdoor unit failure mode recall function
9-time blink 2.5 seconds OFF	FC	Nonvolatile memory data	5-time blink 2.5 seconds OFF	Nonvolatile memory data cannot be read properly.	• Replace the inverter P.C. board.	○	○
	U6	Power module (IC700)	6-time blink 2.5 seconds OFF	The interface short circuit occurs in the output of the power module (IC700). The compressor winding shorts circuit.	• Refer to 10-5.④ "How to check inverter/compressor".	—	○
10-time blink 2.5 seconds OFF	U7	Discharge temperature	—	Temperature of discharge temperature thermistor has been 122°F (50°C) or less for 20 minutes.	• Refer to 10-5.⑤ "Check of LEV". • Check refrigerant circuit and refrigerant amount.	—	○
11-time blink 2.5 seconds OFF	UJ	Bus-bar voltage (DC)	8-time blink 2.5 seconds OFF	Bus-bar voltage of inverter cannot be detected normally.	• Refer to 10-5.④ "How to check inverter/compressor".	—	○
	UH	Each phase current of compressor	9-time blink 2.5 seconds OFF	Each phase current of compressor cannot be detected normally.			
13-time blink 2.5 seconds OFF	Fd	Abnormal of wrong voltage power supply connected.	—	When 100 V power supply is connected to 200 V model.	• Check power supply voltage	○	○
14-time blink 2.5 seconds OFF *1	UE	Stop valve (Closed valve)	14-time blink 2.5 seconds OFF	• Closed valve is detected by compressor current. • An abnormality of the indoor thermistors is detected.	• Check stop valve. • Refer to "TEST POINT DIAGRAM AND VOLTAGE" on the service manual of indoor unit for the characteristics of the thermistors. (Do not start the operation again without repair to prevent hazards.)	○	○
	P8	Pipe temperature	16-time blink 2.5 seconds OFF	• The indoor coil thermistor detects an abnormal temperature. • An abnormality of the indoor thermistors is detected.	• Replace the inverter P.C. board. • Refer to "TEST POINT DIAGRAM AND VOLTAGE" on the service manual of indoor unit for the characteristics of the thermistors. (Do not start the operation again without repair to prevent hazards.)	○	○
16-time blink 2.5 seconds OFF *1	PL	Outdoor refrigerant system abnormality	1-time blink 2.5 seconds OFF	• A closed valve and air trapped in the refrigerant circuit are detected based on the temperature sensed by the indoor and outdoor thermistors and the current of the compressor. • An abnormality of the indoor thermistors is detected.	• Check for a gas leak in a connecting piping etc. • Check the stop valve. • Refer to 10-5.⑤ "Check of outdoor refrigerant circuit". • Refer to "TEST POINT DIAGRAM AND VOLTAGE" on the service manual of indoor unit for the characteristics of the thermistors. (Do not start the operation again without repair to prevent hazards.)	○	○

*1 There is possibility that diesel explosion may occur due to the air mixed in the refrigerant circuit.

First, ensure that there are no leakage points on the valves, flare connections, etc. that allow the air to flow into the refrigerant circuit, or no blockage points (e.g. clogged or closed valves) in the refrigerant circuit that cause an increase in pressure.

If there is no abnormal point like above and the system operates cooling mode normally, the indoor thermistor might have a problem, resulting in false detection. Check both the indoor coil thermistor and the room temperature thermistor, and replace faulty thermistor(s), if any.

NOTE: Do not start the operation again without repair to prevent hazards.

10-3. TROUBLESHOOTING CHECK TABLE


No.	Symptom	LED indication	Abnormal point/ Condition	Condition	Remedy
1	Outdoor unit does not operate.	1-time blink every 2.5 seconds	Outdoor power system	Overcurrent protection cut-out operates 3 consecutive times within 1 minute after the compressor gets started.	• Reconnect connector of compressor. • Refer to 10-5.④ "How to check inverter/compressor". • Check stop valve.
2			Outdoor thermistors	Discharge temperature thermistor, fin temperature thermistor, defrost thermistor, outdoor heat exchanger temperature thermistor or ambient temperature thermistor shorts or opens during compressor running.	• Refer to 10-5.③ "Check of outdoor thermistors".
				P.C. board temperature thermistor shorts or opens during compressor running.	• Replace inverter P.C. board.
3			Outdoor control system	Nonvolatile memory data cannot be read properly. (The left lamp of the OPERATION INDICATOR lamp on the indoor unit lights up or blinks 7-time.)	• Replace inverter P.C. board.
4		6-time blink 2.5 seconds OFF	Serial signal	The communication fails between the indoor and outdoor unit for 3 minutes.	• Refer to 10-5.⑤ "How to check miswiring and serial signal error".
5		11-time blink 2.5 seconds OFF	Stop valve/ Closed valve	Closed valve is detected by compressor current.	• Check stop valve.
6		FX06/09/12 14-time blink 2.5 seconds OFF	Outdoor unit (Other abnormality)	Outdoor unit is defective.	• Refer to 10-2.2. "Flow chart of the detailed outdoor unit failure mode recall function".
7		16-time blink 2.5 seconds OFF	4-way valve/ Pipe temperature	The 4-way valve does not work properly. The indoor coil thermistor detects an abnormal temperature.	• Refer to 10-5.⑥ "Check of R.V. coil". • Replace the inverter P.C. board.
8		17-time blink 2.5 seconds OFF	Outdoor refrigerant system abnormality	A closed valve and air trapped in the refrigerant circuit are detected based on the temperature sensed by the indoor and outdoor thermistors and the current of the compressor.	• Check for a gas leak in a connecting piping etc. • Check the stop valve. • Refer to 10-5.⑦ "Check of outdoor refrigerant circuit".
9	'Outdoor unit stops and restarts 3 minutes later' is repeated.	2-time blink 2.5 seconds OFF	Overcurrent protection	Large current flows into the power module (IC700).	• Reconnect connector of compressor. • Refer to 10-5.④ "How to check inverter/compressor". • Check stop valve.
10		3-time blink 2.5 seconds OFF	Discharge temperature overheat protection	Temperature of discharge temperature thermistor exceeds 241°F (116°C), compressor stops. Compressor can restart if discharge temperature thermistor reads 212°F (100°C) or less 3 minutes later.	• Check refrigerant circuit and refrigerant amount. • Refer to 10-5.⑧ "Check of LEV".
11		4-time blink 2.5 seconds OFF	Fin temperature /P.C. board temperature thermistor overheat protection	Temperature of the fin temperature thermistor on the heat sink exceeds 167 - 187°F (75 - 86°C) (FX06/09/12)/167 - 176°F (75 - 80°C) (FX15/18/24) or temperature of P.C. board temperature thermistor on the inverter P.C. board exceeds 162 - 185°F (72 - 85°C) (FX06/09/12)/158 - 167°F (70 - 75°C) (FX15/18/24).	• Check around outdoor unit. • Check outdoor unit air passage. • Refer to 10-5.① "Check of outdoor fan motor".
12		5-time blink 2.5 seconds OFF	High pressure protection	Indoor coil thermistor exceeds 158°F (70°C) in HEAT mode. Defrost thermistor exceeds 158°F (70°C) in COOL mode.	• Check refrigerant circuit and refrigerant amount. • Check stop valve.
13		8-time blink 2.5 seconds OFF	Compressor synchronous abnormality	The waveform of compressor current is distorted.	• Reconnect connector of compressor. • Refer to 10-5.④ "How to check inverter/compressor".
14		10-time blink 2.5 seconds OFF	Outdoor fan motor	Outdoor fan has stopped 3 times in a row within 30 seconds after outdoor fan startup.	• Refer to 10-5.① "Check of outdoor fan motor". • Refer to 10-5.① "Check of inverter P.C. board".
15		12-time blink 2.5 seconds OFF	Each phase current of compressor	Each phase current of compressor cannot be detected normally.	• Refer to 10-5.④ "How to check inverter/compressor".
16		13-time blink 2.5 seconds OFF	Bus-bar voltage (DC)	Bus-bar voltage of inverter cannot be detected normally.	• It occurs with following case. • Instantaneous power voltage drop. (Short time power failure) (FX15/18/24) • Refer to 10-5.⑨ "Check of power supply". (FX15/18/24) • Refer to 10-5.④ "How to check inverter/compressor".



No.	Symptom	LED indication	Abnormal point/ Condition	Condition		Remedy	
17	Outdoor unit operates.	1-time blink 2.5 seconds OFF	Deceleration of the operational frequency of the compressor by the current protection control	FX06/09/12	When the input current exceeds approximately 10A, compressor frequency lowers.	The unit is normal, but check the following. • Check if indoor filters are clogged. • Check if refrigerant is short. • Check if indoor/outdoor unit air circulation is short cycled.	
				FX15/18/24	Current from power outlet is nearing breaker capacity.		
18		3-time blink 2.5 seconds OFF	Deceleration of the operational frequency of the compressor by the high pressure protection	Temperature of indoor coil thermistor exceeds 131°F (55°C) in HEAT mode, compressor frequency lowers.			
				Indoor coil thermistor reads 46°F (8°C) or less in COOL mode, compressor frequency lowers.			
19		4-time blink 2.5 seconds OFF	Deceleration of the operational frequency of the compressor by the discharge temperature protection	Temperature of discharge temperature thermistor exceeds 232°F (111°C), compressor frequency lowers.			• Check refrigerant circuit and refrigerant amount. • Refer to 10-5.Ⓔ “Check of LEV”. • Refer to 10-5.Ⓔ “Check of outdoor thermistors”.
20	FX06/09/12 5-time blink 2.5 seconds OFF	Outside temperature thermistor protection	When the outside temperature thermistor shorts or opens, protective operation without that thermistor is performed.		• Refer to 10-5.Ⓔ “Check of outdoor thermistors”.		
21	Outdoor unit operates.	7-time blink 2.5 seconds OFF	Low discharge temperature protection	Temperature of discharge temperature thermistor has been 122°F (50°C) or less for 20 minutes.		• Refer to 10-5.Ⓔ “Check of LEV”. • Check refrigerant circuit and refrigerant amount.	
22		8-time blink 2.5 seconds OFF	FX06/09/12 PAM protection PAM: Pulse Amplitude Modulation	The overcurrent flows into IGBT(Q821) or the bus-bar voltage reaches 394 V or more, PAM stops and restarts.		This is not malfunction. PAM protection will be activated in the following cases: 1 Instantaneous power voltage drop. (Short time power failure) 2 When the power supply voltage is high.	
			FX15/18/24 Zero cross detecting circuit	Zero cross signal cannot be detected.			• It occurs with following cases. 1 Instantaneous power voltage drop. (Short time power failure) 2 Distortion of primary voltage • Refer to 10-5.Ⓔ “Check of power supply”.
23		9-time blink 2.5 seconds OFF	Inverter check mode	The connector of compressor is disconnected, inverter check mode starts.		• Check if the connector of the compressor is correctly connected. Refer to 10-5.Ⓔ “How to check inverter/compressor”.	


NOTE: 1. The location of LED is illustrated at the right figure. Refer to 10-6.1.
2. LED is lit during normal operation.

The blinking frequency shows the number of times the LED blinks after every 2.5-second OFF.
(Example) When the blinking frequency is "2".




Inverter P.C. board

MUZ-FX06/09/12NLHZ



MUZ-FX15/18/24NLHZ



10-4. TROUBLESHOOTING CRITERION OF MAIN PARTS

MUZ-FX06NLHZ MUZ-FX09NLHZ


MUZ-FX12NLHZ MUZ-FX15NLHZ

MUZ-FX18NLHZ MUZ-FX24NLHZ

Part name	Check method and criterion	Figure																				
Defrost thermistor (RT61) Fin temperature thermistor (RT64) Ambient temperature thermistor (RT65) Outdoor heat exchanger temperature thermistor (RT68)	Measure the resistance with a multimeter. Refer to 10-6. "Test point diagram and voltage", 1. "Inverter P.C. board", for the chart of thermistor.																					
Discharge temperature thermistor (RT62)	Measure the resistance with a multimeter. Before measurement, hold the thermistor with your hands to warm it up. Refer to 10-6. "Test point diagram and voltage", 1. "Inverter P.C. board", for the chart of thermistor.																					
Compressor	Measure the resistance between terminals using a multimeter. [Temperature: 14 – 104°F (-10 – 40°C)] <table><tr><td></td><td colspan="3">Normal (Ω)</td></tr><tr><td></td><td>MUZ-FX06NLHZ</td><td>MUZ-FX09NLHZ MUZ-FX12NLHZ MUZ-FX15NLHZ MUZ-FX18NLHZ</td><td>MUZ-FX24NLHZ</td></tr><tr><td>U-V</td><td>1.82 – 2.48</td><td>1.30 – 1.77</td><td>0.60 – 0.82</td></tr><tr><td>U-W</td><td></td><td></td><td></td></tr><tr><td>V-W</td><td></td><td></td><td></td></tr></table>		Normal (Ω)				MUZ-FX06NLHZ	MUZ-FX09NLHZ MUZ-FX12NLHZ MUZ-FX15NLHZ MUZ-FX18NLHZ	MUZ-FX24NLHZ	U-V	1.82 – 2.48	1.30 – 1.77	0.60 – 0.82	U-W				V-W				
	Normal (Ω)																					
	MUZ-FX06NLHZ	MUZ-FX09NLHZ MUZ-FX12NLHZ MUZ-FX15NLHZ MUZ-FX18NLHZ	MUZ-FX24NLHZ																			
U-V	1.82 – 2.48	1.30 – 1.77	0.60 – 0.82																			
U-W																						
V-W																						
Outdoor fan motor	Measure the resistance between lead wires using a multimeter. [Temperature: 14 – 104°F (-10 – 40°C)] <table><tr><td rowspan="2">Color of lead wire</td><td colspan="2">Normal (Ω)</td></tr><tr><td>MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ</td><td>MUZ-FX15NLHZ MUZ-FX18NLHZ MUZ-FX24NLHZ</td></tr><tr><td>RED – BLK BLK – WHT WHT – RED</td><td colspan="2">30 – 46</td></tr></table>	Color of lead wire	Normal (Ω)		MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ	MUZ-FX15NLHZ MUZ-FX18NLHZ MUZ-FX24NLHZ	RED – BLK BLK – WHT WHT – RED	30 – 46														
Color of lead wire	Normal (Ω)																					
	MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ	MUZ-FX15NLHZ MUZ-FX18NLHZ MUZ-FX24NLHZ																				
RED – BLK BLK – WHT WHT – RED	30 – 46																					
R. V. coil (21S4)	Measure the resistance using a multimeter. [Temperature: 14 – 104°F (-10 – 40°C)] <table><tr><td>Normal (kΩ)</td></tr><tr><td>1.88 - 2.29</td></tr></table>	Normal (kΩ)	1.88 - 2.29																			
Normal (kΩ)																						
1.88 - 2.29																						
Expansion valve coil (LEV)	Measure the resistance using a multimeter. [Temperature: 14 – 104°F (-10 – 40°C)] <table><tr><td>Color of lead wire</td><td>Normal (Ω)</td></tr><tr><td>BRN – ORN</td><td rowspan="4">37 – 54</td></tr><tr><td>BRN – WHT</td></tr><tr><td>RED – BLU</td></tr><tr><td>RED – YLW</td></tr></table>	Color of lead wire	Normal (Ω)	BRN – ORN	37 – 54	BRN – WHT	RED – BLU	RED – YLW														
Color of lead wire	Normal (Ω)																					
BRN – ORN	37 – 54																					
BRN – WHT																						
RED – BLU																						
RED – YLW																						
Defrost heater	Measure the resistance using a multimeter. [Temperature: 14 – 104°F (-10 – 40°C)] <table><tr><td colspan="2">Normal (Ω)</td></tr><tr><td>MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ</td><td>MUZ-FX15NLHZ MUZ-FX18NLHZ MUZ-FX24NLHZ</td></tr><tr><td>802 – 990</td><td>396 – 461</td></tr></table>	Normal (Ω)		MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ	MUZ-FX15NLHZ MUZ-FX18NLHZ MUZ-FX24NLHZ	802 – 990	396 – 461															
Normal (Ω)																						
MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ	MUZ-FX15NLHZ MUZ-FX18NLHZ MUZ-FX24NLHZ																					
802 – 990	396 – 461																					

10-5. TROUBLESHOOTING FLOW

Ⓐ How to check inverter/compressor



Ⓑ Check of open phase

- With the connector between the compressor and the power module (IC700) disconnected, activate the inverter and check if the inverter is normal by measuring **the voltage balance** between the terminals.

Output voltage is 50 - 130 V. (The voltage may differ according to the multimeter.)

<< Operation method>>

Start cooling or heating operation by pressing the emergency operation switch on the indoor unit. (TEST RUN OPERATION: Refer to 7-6.)

<<Measurement point>>

At 3 points

*Measure AC voltage between the lead wires at 3 points.

BLK (U)-WHT (V)

BLK (U)-RED (W)


WHT(V)-RED (W)

NOTE: 1. Output voltage varies according to power supply voltage.

2. Measure the voltage by analog type multimeter.

3. During this check, LED of the inverter P.C. board blinks 9 times. (Refer to 10-6.1.)

Ⓒ Check of compressor



D Check of compressor winding

- Disconnect the connector between the compressor and the power module (IC700), and measure the resistance between the compressor terminals.

<<Measurement point>>

At 3 points *Measure the resistance between the lead wires at 3 points.

BLK-WHT

BLK-RED

WHT-RED

<<Judgement>>

Refer to 10-4.

0 [Ω] Abnormal [short]

Infinite [Ω] Abnormal [open]

NOTE: Be sure to zero the ohmmeter before measurement.

E Check of compressor operation time

- Connect the compressor and activate the inverter. Then measure the time until the inverter stops due to overcurrent.


<<Operation method>>

Start heating or cooling operation by pressing the emergency operation switch on the indoor unit. (TEST RUN OPERATION: Refer to 7-6.)

<<Measurement>>

Measure the time from the start of compressor to the stop of compressor due to overcurrent.

<<Judgement>>



F Check of compressor start failure

Confirm that ①~④ is normal.

• Electrical circuit check

①. Contact of the compressor connector

②. Output voltage of inverter P.C. board and balance of them (See 10-5.⑥)

③. Direct current voltage between DB61(+) and (-) (FX06/09/12)/IC700(P) and (N) (FX15/18/24) on the inverter P.C. board

④. Voltage between outdoor terminal block S1-S2

Does the compressor run for 10 seconds or more after it starts?

Yes

Check the refrigerant circuit.
Check the stop valve.

No


After the compressor is heated with a drier, does the compressor start? *1

No

Replace the compressor.

Yes

Compressor start failure. Activate pre-heat control.
(Refer to 9-2. "PRE-HEAT CONTROL SETTING")



*1
Heat the compressor with a drier for about 20 minutes. Do not recover refrigerant gas while heating.

Ⓒ Check of outdoor thermistors

Disconnect the connector of thermistor in the inverter P.C. board (see below table), and measure the resistance of thermistor.

Is the resistance of thermistor normal?
(Refer to 10-6.1.)

No

Replace the thermistor except RT64.
When RT64 is abnormal, replace the inverter P.C. board.

Yes

Reconnect the connector of thermistor.
Turn ON the power supply and press the emergency operation switch.

Does the unit operate for 10 minutes or more
without showing thermistor abnormality?

No

Replace the inverter P.C. board.

Yes

OK
(Cause is poor contact.)

MUZ-FX06/09/12

Thermistor	Symbol	Connector, Pin No.	Board
Defrost	RT61	Between CN641 pin1 and pin2	Inverter P.C. board
Discharge temperature	RT62	Between CN641 pin3 and pin4	
Fin temperature	RT64	Between CN642 pin1 and pin2	
Ambient temperature	RT65	Between CN643 pin1 and pin2	
Outdoor heat exchanger temperature	RT68	Between CN644 pin1 and pin3	

MUZ-FX15/18/24


Thermistor	Symbol	Connector, Pin No.	Board
Defrost	RT61	Between CN671 pin1 and pin2	Inverter P.C. board
Discharge temperature	RT62	Between CN671 pin3 and pin4	
Fin temperature	RT64	Between CN673 pin1 and pin2	
Ambient temperature	RT65	Between CN672 pin1 and pin2	
Outdoor heat exchanger temperature	RT68	Between CN671 pin5 and pin6	

H Check of R.V. coil


MUZ-FX06/09/12

- * First of all, measure the resistance of R.V. coil to check if the coil is defective. Refer to 10-4.
- * In case CN721 is disconnected or R.V. coil is open, voltage is generated between the terminal pins of the connector although no signal is being transmitted to R.V. coil.
Check if CN721 is connected.

Unit operates in COOL mode even if it is set to HEAT mode.




Unit operates in HEAT mode even if it is set to COOL mode.




MUZ-FX15/18/24

- * First of all, measure the resistance of R.V. coil to check if the coil is defective. Refer to 10-4.
- * In case CN602 is disconnected or R.V. coil is open, voltage is generated between the terminal pins of the connector although no signal is being transmitted to R.V. coil.
Check if CN602 is connected.

Unit operates in COOL mode even if it is set to HEAT mode.



Unit operates in HEAT mode even if it is set to COOL mode.



I Check of outdoor fan motor

Disconnect the connectors CN931 and CN932 from the inverter P.C. board. Check the connection between the connector CN931 and CN932.

Is the resistance between each terminal of outdoor fan motor normal?
(Refer to 10-4.)

No

Replace the outdoor fan motor.

Yes

Disconnect CN932 from the inverter P.C. board, and turn on the power supply.

Rotate the outdoor fan motor manually and measure the voltage of CN931.
Between 1(+) and 5(-)
Between 2(+) and 5(-)
Between 3(+) and 5(-)

(Fixed to either 5 or 0 V DC) Does the voltage between each terminal become 5 and 0 V DC repeatedly?

No

Yes

No

Does the outdoor fan motor rotate smoothly?

Yes

Replace the inverter P.C. board.

J Check of power supply

Disconnect the connector between the compressor and the power module (IC700). Turn ON power supply and press the emergency operation switch.

Does the left lamp of the OPERATION INDICATOR lamp on the indoor unit light up?

No

Rectify indoor/outdoor connecting wire.

Yes

Is there voltage 208/230 V AC between the indoor terminal block S1 and S2?

Replace the indoor electronic control P.C. board.

Yes

Is there bus-bar voltage 260 - 370 V DC between DB61 (+) and DB61 (-) (FX06/09/12)/294 - 370 V DC between IC700 (P) and (N) (FX15/18/24) on the inverter P.C. board? (Refer to 10-6.1.)

Yes

Does LED on the inverter P.C. board light up or blink? (Refer to 10-6.1.)

No


Replace the inverter P.C. board.

No


Check the electric parts in main circuit.

If lights up, OK.
If blinks, refer to 10-3.

MUZ-FX06/09/12



MUZ-FX15/18/24




K Check of LEV (Expansion valve)

Turn ON the power supply.

<Preparation of the remote controller>

- ① While pressing both Operation select button and TEMP $\oplus$ button on the remote controller at the same time, press RESET button.
- ② First, release RESET button.
Hold down the other 2 buttons for another 3 seconds.
Make sure that the indicators on the LCD screen shown in the right figure are all displayed. Then release the buttons.



Press OFF/ON (stop/operate) button of the remote controller (the set temperature is displayed) with the remote controller headed towards the indoor unit. *1

Expansion valve operates in full-opening direction.

Do you hear the expansion valve "click, click....."?
Do you feel the expansion valve vibrate when touching it?

Yes

OK

No

Is LEV coil properly fixed to the expansion valve?

No

Properly fix the LEV coil to the expansion valve.

Yes

Does the resistance of LEV coil have the characteristics? (Refer to 10-4.)

Yes

Measure each voltage between connector pins of CN724 on the inverter P.C. board.
1. Pin ③ (-) — Pin ① (+)
2. Pin ④ (-) — Pin ① (+)
3. Pin ⑤ (-) — Pin ① (+)
4. Pin ⑥ (-) — Pin ① (+)
Is there about 3 - 5 V DC between each?
NOTE: Measure the voltage by an analog multimeter.

No

Replace the inverter P.C. board.

No

Replace the LEV coil.


Yes

Replace the expansion valve.


NOTE: After check of LEV, take the following steps.

1. Turn OFF the power supply and turn it ON again.
2. Press RESET button on the remote controller.

L Check of inverter P.C. board



M How to check miswiring and serial signal error



N Check of defrost heater

Check the following points before checking electric continuity.

1. Does the resistance of ambient temperature thermistor have the characteristics? Refer to 10-6.1.
2. Is the resistance of defrost heater normal? Refer to 10-4.
3. Does the heater protector remain conducted (not open)?
4. Are both ambient temperature thermistor and circuit of defrost heater securely connected to connectors?

In HEAT mode, for more than 5 minutes, let the ambient temperature thermistor continue to read 32°F (0°C) or below, and let the defrost thermistor continue to read 30°F (-1°C) or below.

NOTE: In case both thermistors are more than the above temperature, cool them with cold water etc.

Is there 208/230 V AC between CN601 ① and ② on the inverter P.C. board? Refer to 10-6.1.

Yes

Not the problem of the inverter P.C. board.

No

Replace the inverter P.C. board.

O Check of outdoor refrigerant circuit

Has the operation stopped during pump down?

Yes

The operation has stopped to prevent the diesel explosion caused by air trapped in the refrigerant circuit. Close the stop valve, and disconnect the power plug or turn the breaker OFF.

CAUTION : Do not start the operation again to prevent hazards.

No

Was the operation started with the stop valve closed, and was it opened during operation?

Yes


The unit occasionally stops when the stop valve is opened or closed during operation. Open the stop valve and start the cooling operation again.

No


The refrigerant gas amount may be 60% or less than the normal amount. Identify where the gas is leaking from, and fix the leak.

P Check of compressor protector

Disconnect the connector of compressor protector in the inverter P.C. board, and check the conduction of compressor protector.



Q Electromagnetic noise enters into TV sets or radios



Even if all of the above conditions are fulfilled, the electromagnetic noise may enter, depending on the electric field strength or the installation condition (combination of specific conditions such as antennas or wiring). Check the following before asking for service.

1. Devices affected by the electromagnetic noise
TV sets, radios (FM/AM broadcast, shortwave)
2. Channel, frequency, broadcast station affected by the electromagnetic noise
3. Channel, frequency, broadcast station unaffected by the electromagnetic noise
4. Layout of:
indoor/outdoor unit of the air conditioner, indoor/outdoor wiring, ground wire, antennas, wiring from antennas, receiver
5. Electric field intensity of the broadcast station affected by the electromagnetic noise
6. Presence or absence of amplifier such as booster
7. Operation condition of air conditioner when the electromagnetic noise enters in
 - 1) Turn OFF the power supply once, and then turn ON the power supply. In this situation, check for the electromagnetic noise.
 - 2) Within 3 minutes after turning ON the power supply, press OFF/ON (stop/operate) button on the remote controller for power ON, and check for the electromagnetic noise.
 - 3) After a short time (3 minutes later after turning ON), the outdoor unit starts running. During operation, check for the electromagnetic noise.
 - 4) Press OFF/ON (stop/operate) button on the remote controller for power OFF, when the outdoor unit stops but the indoor/outdoor communication still runs on. In this situation, check for the electromagnetic noise.





10-6. TEST POINT DIAGRAM AND VOLTAGE

1. Inverter P.C. board


MUZ-FX06NLHZ

MUZ-FX09NLHZ




MUZ-FX12NLHZ



MUZ-FX15NLHZ
MUZ-FX18NLHZ
MUZ-FX24NLHZ



Defrost thermistor(RT61)
Ambient temperature thermistor(RT65)
Outdoor heat exchanger temperature thermistor(RT68)




2. Fuse P.C. board

MUZ-FX15NLHZ

MUZ-FX18NLHZ

MUZ-FX24NLHZ



<Detaching method of the terminal with locking mechanism>

The terminal which has the locking mechanism can be detached as shown below.



There are 2 types of the terminal with locking mechanism.

The terminal without locking mechanism can be detached by pulling it out.

Check the shape of the terminal before detaching.

(1) Slide the sleeve and check if there is a locking lever or not.

(2) The terminal with the connector shown below has the locking mechanism.


**11-1. MUZ-FX06NLHZ MUZ-FX09NLHZ MUZ-FX12NLHZ**



NOTE: Turn OFF the power supply before disassembly.

→ : Indicates the visible parts in the photos/figures.

---> : Indicates the invisible parts in the photos/figures.

OPERATING PROCEDURE	PHOTOS/FIGURES
1. Removing the cabinet (1) Remove the screws of the service panel. (2) Remove the screws of the top panel. (3) Remove the screw of the valve cover. (4) Remove the service panel. (5) Remove the top panel. (6) Remove the valve cover. (7) Remove the screws fixing the conduit cover. (Photo 5) (8) Remove the conduit cover. (9) Remove the screw fixing the conduit plate. (Photo 6) (10) Remove the conduit plate. (11) Disconnect the power supply cord and indoor/outdoor connecting wire. (12) Remove the screws of the cabinet. (13) Remove the cabinet. (14) Remove the screws of the back panel. (15) Remove the back panel. NOTE: If the red labels have been removed during the operation, put them back in the original position after the operation. Red labels indicate the use of flammable refrigerants. (Figure 1)	Photo 1 Screws of the top panel Screws of the cabinet Screws of the cabinet Photo 2 Screws of the top panel Screws of the cabinet Screws of the service panel Screw of the valve cover
Photo 4 Screws of the back panel	Photo 3 Direction to remove Hooks of the service panel Figure 1 Red label



OPERATING PROCEDURE	PHOTOS/FIGURES
Photo 5 Screws of the conduit cover (These screws are different shape from the other screws. Do not mix them with the other screws.) 	Photo 6 Screw of the conduit plate (This screw is different in shape from the other screws. Do not mix them with the other screws.) 
2. Removing the inverter assembly and inverter P.C. board (1) Remove the cabinet and panels (refer to section 1). (2) Disconnect the lead wire to the reactor and the following connectors: <Inverter P.C. board> CN721 (R.V. coil) CN931, CN932 (Fan motor) CN641 (Defrost thermistor and discharge temperature thermistor) CN643 (Ambient temperature thermistor) CN644 (Outdoor heat exchanger temperature thermistor) CN724 (Expansion valve coil) CN722 (Defrost heater and heater protector) CN64 (Compressor protector) (3) Remove the compressor connector (CN61). (4) Remove the screws fixing the heat sink support and the separator. (5) Remove the inverter assembly. (6) Remove the screws of the ground wires. (7) Remove the heat sink support from the P.C. board support. (Photo 9) (8) Remove the PB cover. (9) Remove the screw of the inverter P.C. board and remove the inverter P.C. board from the P.C. board support. (Photo 10)	Photo 7 Screw of the heat sink support and the separator PB cover  Photo 8 Lead wires of the defrost heater 

OPERATING PROCEDURE

* Connection procedure when attaching the inverter P.C. board (Photo 11)

1. Connect the lead wires of the heat exchanger temperature thermistor, the defrost thermistor and discharge temperature thermistor to the connector on the inverter P.C. board. Pull the lead wires toward you and put them on the center hook on the P.C. board support.
2. Connect the lead wires of the expansion valve coil to the connector on the inverter P.C. board. Pull the lead wires toward you and put them on the right hook on the P.C. board support.
3. Connect the lead wires of the ambient temperature thermistor to the connector on the inverter P.C. board. Pull the lead wires toward you and put them on the left hook on the P.C. board support so that the fan motor lead wires are bundled up as shown in Photo 11.
4. Hook the lead wires of the defrost heater and the heater protector. (Photo 8)

Photo 9 (Inverter assembly)








Photo 10



PHOTOS/FIGURES

Photo 11



OPERATING PROCEDURE	PHOTOS/FIGURES
3. Removing the discharge temperature thermistor, defrost thermistor, outdoor heat exchanger temperature thermistor and ambient temperature thermistor (1) Remove the cabinet and panels (refer to section 1). (2) Disconnect the lead wire to the reactor and the following connectors: <Inverter P.C. board> CN641 (Defrost thermistor and discharge temperature thermistor) CN643 (Ambient temperature thermistor) CN644 (Outdoor heat exchanger temperature thermistor) (3) Pull out the discharge temperature thermistor from its holder. (Photo 14) (4) Pull out the defrost thermistor from its holder. (5) Pull out the outdoor heat exchanger temperature thermistor from its holder. (6) Pull out the ambient temperature thermistor from its holder.	Photo 12 
4. Removing outdoor fan motor (1) Remove the cabinet and panels (refer to section 1). (2) Disconnect the following connectors: <Inverter P.C. board> CN931, CN932 (Fan motor) (3) Remove the propeller fan nut. (4) Remove the propeller fan. (5) Remove the screws fixing the fan motor. (6) Remove the fan motor.	Photo 13 

OPERATING PROCEDURE

5. Removing R. V. coil

- (1) Remove the cabinet and panels (refer to section 1).
- (2) Disconnect the following connectors:
<Inverter P.C. board>
CN721 (R.V. coil)
- (3) Remove the R.V. coil.


6. Removing the compressor and 4-way valve

- (1) Remove the cabinet and panels (refer to section 1).
- (2) Remove the inverter assembly (refer to section 2).
- (3) Remove the screws fixing the reactor.
- (4) Remove the reactor.
- (5) Remove the soundproof felt.
- (6) Recover gas from the refrigerant circuit.
NOTE: Recover gas from the pipes until the pressure gauge shows 0 psig.
- (7) Detach the brazed part of the suction and the discharge pipe connected with compressor.
- (8) Remove the compressor nuts.
- (9) Remove the compressor.
- (10) Detach the brazed part of pipes connected with 4-way valve.

NOTE: If the red labels have been removed during the operation, put them back in the original position after the operation. Red labels indicate the use of flammable refrigerants. (Figure 3)

Figure 2

Attach the compressor protector to the protector holder with the surface on which the model name is printed facing the area hatched in the figure.



PHOTOS/FIGURES

Photo 14

Screw of the R.V. coil

Discharge temperature thermistor

Compressor protector




Photo 15

Discharge pipe brazed part




Suction pipe brazed part

Brazed parts of 4-way valve






Figure 3

Red labels




11-2. MUZ-FX15NLHZ MUZ-FX18NLHZ MUZ-FX24NLHZ

NOTE: Turn OFF the power supply before disassembly.

OPERATING PROCEDURE	PHOTOS/FIGURES
1. Removing the cabinet (1) Remove the screws of the service panel. (2) Remove the screws of the top panel. (3) Remove the screw of the valve cover. (4) Remove the service panel. (5) Remove the top panel. (6) Remove the valve cover. (7) Remove the screws fixing the conduit cover. (Photo 5) (8) Remove the conduit cover. (9) Remove the screw fixing the conduit plate. (Photo 6) (10) Remove the conduit plate. (11) Disconnect the power supply and indoor/outdoor connecting wire. (12) Remove the screws of the cabinet. (13) Remove the cabinet. (14) Remove the screws of the back panel. (15) Remove the back panel. NOTE: If the red labels have been removed during the operation, put them back in the original position after the operation. Red labels indicate the use of flammable refrigerants. (Figure 1)	Photo 2  Screws of the top panel Screws of the service panel Screw of the valve cover Screws of the cabinet Photo 3  Screws of the cabinet Direction to remove Hooks of the service panel Photo 4  Screws of the back panel
Photo 1  Screws of the top panel Screws of the cabinet Figure 1  Red label	


OPERATING PROCEDURE

Photo 5 Screws of the conduit cover



PHOTOS/FIGURES

Photo 6 Screw of the conduit plate



2. Removing the inverter assembly, inverter P.C. board and fuse P.C. board

2-1. Removing the inverter assembly and inverter P.C. board

- (1) Remove the top panel, cabinet and service panel.
(Refer to section 1.)
- (2) Disconnect the lead wire to the reactor and the following connectors:
 - <Inverter P.C. board>
 - CN602 (R.V. coil)
 - CN931, CN932 (Fan motor)
 - CN671 (Defrost thermistor, discharge temperature thermistor and outdoor heat exchanger temperature thermistor)
 - CN672 (Ambient temperature thermistor)
 - CN724 (Expansion valve coil)
 - CN601 (Defrost heater and heater protector)
 - CN64 (Compressor protector)
- (3) Remove the compressor connector (CN61).
- (4) Remove the screws fixing the heat sink support and the separator.
- (5) Remove the screws fixing the P.C. board support and the motor support.
- (6) Remove the inverter assembly.
- (7) Remove the screws of the ground wires and the terminal block support.
- (8) Remove the screw of the heat sink support, and the heat sink support from the P.C. board support.

Photo 7





Photo 8 (Inverter assembly)



OPERATING PROCEDURE

* Connection procedure when attaching the inverter P.C. board (Photo 8, 9, 10, 11, 12)

1. Attach the heat sink support to the P.C. board support.
2. Hook the lead wires of the compressor, the reactor and the P.C. board to each hooks on the heat sink support as shown in Photo 11.
3. Connect the lead wires of the expansion valve coil to the connector on the inverter P.C. board. Pull the lead wires of the expansion valve coil toward you and put them on the left hook on the P.C. board support as shown in Photo 12.
4. Hook the lead wires of the compressor, fuse P.C. board, discharge temperature thermistor, defrost thermistor and expansion valve coil to each hook and tighten the wires with the fastener as shown in Photo 12.
5. Hook the lead wires of the defrost heater and the heater protector. (Photo 9)

PHOTOS/FIGURES

Photo 11




Photo 9




Photo 10





Photo 12




OPERATING PROCEDURE

PHOTOS/FIGURES

2-2. Removing the fuse P.C. board

- (1) Remove the top panel, cabinet and service panel. (Refer to section 1.)
- (2) Disconnect the lead wire to the reactor and the inverter P.C. board connectors. (Refer to section 2-1. (2))
- (3) Remove the compressor connector (CN61).
- (4) Remove the screws fixing the heat sink support and the separator.
- (5) Remove the screws fixing the P.C. board support and the motor support.
- (6) Remove the fixing screws of the terminal block support and the back panel.
- (7) Remove the inverter assembly.
- (8) Remove the following disconnected connectors:
<Fuse P.C. board>
CN65, CN66 (Terminal block)
- (9) Remove the fuse P.C. board from the supports.

Photo 13





Pinch the stopper of the support, and push it into the hole to remove the fuse P.C. board.



3. Removing the discharge temperature thermistor, defrost thermistor, outdoor heat exchanger temperature thermistor and ambient temperature thermistor




- (1) Remove the cabinet and panels. (Refer to section 1.)
- (2) Disconnect the lead wire to the reactor and the following connectors:
<Inverter P.C. board>
CN671 (Defrost thermistor, discharge temperature thermistor and outdoor heat exchanger temperature thermistor)
CN672 (Ambient temperature thermistor)
- (3) Pull out the discharge temperature thermistor from its holder. (Photo 16)
- (4) Pull out the defrost thermistor from its holder.
- (5) Pull out the outdoor heat exchanger temperature thermistor from its holder. (Photo 14)
- (6) Pull out the ambient temperature thermistor from its holder.

Photo 14





OPERATING PROCEDURE	PHOTOS/FIGURES
4. Removing outdoor fan motor (1) Remove the top panel, cabinet and service panel. (Refer to section 1.) (2) Disconnect the following connectors: <Inverter P.C. board> CN931, CN932 (Fan motor) (3) Remove the propeller fan nut. (4) Remove the propeller fan. (5) Remove the screws fixing the fan motor. (6) Remove the fan motor.	Photo 15  Propeller fan nut Propeller fan Screws of the outdoor fan motor
5. Removing R. V. coil (1) Remove the cabinet and panels. (Refer to section 1.) (2) Disconnect the following connectors: <Inverter P.C. board> CN602 (R.V. coil) (3) Remove the R.V. coil.	Photo 16  Brazed part of the discharge pipe Discharge temperature thermistor Screw of the R.V. coil Compressor protector Brazed part of the suction pipe

OPERATING PROCEDURE	PHOTOS/FIGURES
6. Removing the compressor and 4-way valve (1) Remove the cabinet and panels. (Refer to section 1.) (2) Remove the inverter assembly. (Refer to section 2.) (3) Remove the screws fixing the reactor. (4) Remove the reactor. (5) Remove the soundproof felt. (6) Recover gas from the refrigerant circuit. NOTE: Recover gas from the pipes until the pressure gauge shows 0 psig. (7) Detach the brazed part of the suction and the discharge pipe connected with compressor. (Photo 16) (8) Remove the compressor nuts. (9) Remove the compressor. (10) Detach the brazed parts of 4-way valve and pipe. NOTE: If the red labels have been removed during the operation, put them back in the original position after the operation. Red labels indicate the use of flammable refrigerants. (Figure 2)	Photo 17  Brazed parts of 4-way valve Figure 2  Red labels Figure 3 Attach the compressor protector to the protector holder with the surface on which the model name is printed facing the area hatched in the figure. 

MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN

© Copyright 2024 MITSUBISHI ELECTRIC CORPORATION
Issured: Dec. 2024. No. OBH946 REVISED EDITION-B
Issured: Nov. 2024. No. OBH946 REVISED EDITION-A
Published: Sep. 2024. No. OBH946
Made in Japan

Specifications are subject to change without notice.